


40109600200



GR4 Wiring Diagram




Technical Assistance:

If you need assistance setting up or using your Gator product now or in the future, call


Gator Support. Australia

TEL: 03 - 8587 8808


Sensor Installation




The height from the center of sensor to the ground should be between 50~65CM, the best height is 55CM




Please install correctly according to the above picture to avoid wrong warning.



Please make sure the diameter of the drill is the same as the sensor before drilling



Plug the sensor into the hole



If installation tape is unavailable, please clip the edge of sensor as picture shown

