

DCT-25 ARC to Analog Audio Converter



Operation Manual



DISCLAIMERS

The information in this manual has been carefully checked and is believed to be accurate. Cypress Technology assumes no responsibility for any infringements of patents or other rights of third parties which may result from its use.

Cypress Technology assumes no responsibility for any inaccuracies that may be contained in this document. Cypress also makes no commitment to update or to keep current the information contained in this document.

Cypress Technology reserves the right to make improvements to this document and/or product at any time and without notice.

COPYRIGHT NOTICE

No part of this document may be reproduced, transmitted, transcribed, stored in a retrieval system, or any of its part translated into any language or computer file, in any form or by any means electronic, mechanical, magnetic, optical, chemical, manual, or otherwise—without express written permission and consent from Cypress Technology.

© Copyright 2012 by Cypress Technology.

All Rights Reserved.

Version 1.1 August 2011

TRADEMARK ACKNOWLEDGMENTS

All products or service names mentioned in this document may be trademarks of the companies with which they are associated.



SAFETY PRECAUTIONS

Please read all instructions before attempting to unpack, install or operate this equipment and before connecting the power supply.

Please keep the following in mind as you unpack and install this equipment:

- Always follow basic safety precautions to reduce the risk of fire, electrical shock and injury to persons.
- To prevent fire or shock hazard, do not expose the unit to rain, moisture or install this product near water.
- Never spill liquid of any kind on or into this product.
- Never push an object of any kind into this product through any openings or empty slots in the unit, as you may damage parts inside the unit.
- Do not attach the power supply cabling to building surfaces.
- Use only the supplied power supply unit (PSU). Do not use the PSU if it is damaged.
- Do not allow anything to rest on the power cabling or allow any weight to be placed upon it or any person walk on it.
- To protect the unit from overheating, do not block any vents or openings in the unit housing that provide ventilation and allow for sufficient space for air to circulate around the unit.

REVISION HISTORY

VERSION NO.	DATE DD/MM/YY	SUMMARY OF CHANGE	
VRO	07/01/14	Preliminary Release	
VS1	12/03/14	Amended Text/Diagrams	



CONTENTS

1. Introduction	1
2. Applications	1
3. Package Contents	1
4. System Requirements	1
5. Features	1
6. Operation Controls and Functions	2
6.1 Front Panel	2
6.2 Rear Panel	2
7. Connection Diagram	3
8. Specifications	4
8.1 Technical Specifications	4
8.2 Audio Specifications	4
9. Acronyms	5



1. INTRODUCTION

The ARC to Analog Audio Converter is designed to extract the audio signal from an HDTV's HDMI ARC (Audio Return Channel) connection and convert it to an analog stereo signal, allowing the connection of an HDTV with HDMI-only output to non-HDMI equipped amplifiers, AV receivers or active speakers. It supports HDMI audio sampling rates up to 192 kHz and analog stereo (2 CH) audio output.

2. APPLICATIONS

- HDMI/ARC audio conversion to analog stereo output
- TV audio output over external analog sound system/active speakers

3. PACKAGE CONTENTS

- 1×ARC to Analog Audio Converter
- 1×5V/1A DC Power Adaptor
- Operation Manual

4. SYSTEM REQUIREMENTS

TV/Display with ARC enabled HDMI connection and analog stereo sound system or active speakers.


5. FEATURES

- Supports Digital to Analog audio Conversion (DAC)
- Extracts the HDMI audio signal from a HDTV's ARC connection and converts it to a line level analog stereo output
- Supports HDMI audio sampling rates up to 192kHz
- Simultaneous audio from the TV speakers and Line Level output
- Supports volume control from the TV's remote control via CEC function
- Plug and play with no software required



6. OPERATION CONTROLS AND FUNCTIONS

6.1 Front Panel




- **1 DC 5V:** Connect the 5V DC power supply to the unit and plug the adaptor into an AC outlet.
- **2 HDMI:** Connect to a TV/Display's ARC enabled HDMI connector with an active audio signal.

Note:


- 1. To ensure proper ARC audio performance, an HDMI High Speed cable is required.
- 2. The ARC function must be enabled in the TV/Display's settings. Please refer to the manual for your model of TV/Display.
- **3 POWER LED:** The LED will illuminate when the device is connected to an active power supply.

6.2 Rear Panel



1 LINE OUT: Connect the R/L OUT to an analog stereo (R/L) amplifier or active speakers for audio output.







8. SPECIFICATIONS

8.1 Technical Specifications

HDMI ARC Port	1×HDMI (Female)		
Output Port	1×Analog Stereo (2 RCA)		
HDMI Audio	Up to 192kHz		
Sampling Rates			
ESD Protection	Human body model: ±8kV (air-gap discharge) ±4kV (contact discharge)		
Power Supply	5 V/1 A DC (US/EU standard, CE/FCC/UL certified)		
Dimensions	55mm (W)×75.5mm (D)×22.5mm(H)/Jacks Excluded		
	55mm (W)×80.5mm (D)×22.5mm(H)/Jacks Included		
Weight	46 g		
Chassis Material	Plastic		
Color	White		
Operating Temperature	0 °C ~ 40 °C/32 °F ~ 104 °F		
Storage Temperature	−20 °C ~ 60°C/−4 °F ~ 140 °F		
Relative Humidity	20 ~ 90 % RH (non-condensing)		
Power Consumption	0.72W		

8.2 Audio Specifications

Input	Output			Frequency	SNR	Crosstalk
Level/Freq.		Level		Response		
HDMI	L/R	2Vrms ±10%	<0.01%	±1 dBFS	>80 dB	<-80 dB
0dB/1kHz						
32 kHz~192 kHz						



9. ACRONYMS

ACRONYM	COMPLETE TERM	
ARC	Audio Return Channel	
DAC	Digital to Analog Converter	
CEC	Consumer Electronic Control	
HDMI	High-Definition Multimedia Interface	



20130327 MPM-DCT25