



C-Assist Set up Guide

Wireless connection to and projection from
PCs Macs and Mobile Devices



CASIO COMPUTER CO., LTD.

Contents

Heading	Page
Wirelessly Connecting your PC/Mac to your Casio Projector	3
Process overview	4
Preparing your Projector	5
Preparing your PC/Mac	8
Making the Connection	14
Wirelessly Connecting your Mobile Device to your Casio Projector	19
Process overview	20
Preparing your Projector	21
Preparing your Mobile Device	24
Making the Connection	26
Enabling internet browsing with C-Assist for Android	31

***Wirelessly Connect your
PC/Mac to your Casio
Projector***



Wireless PC/Mac Connection

Connecting your PC/Mac to your new Casio Projector via a wireless network is a 3 step process:

1. Preparing your Projector



2. Preparing your PC/Mac



3. Making the Connection



1. Preparing your Projector



Preparing your projector

i) Turn your projector on by connecting the power cord to the back of the unit (A) and pressing the power button (B)




ii) Plug your wireless adaptor into the port on the back of your projector marked USB-A. Please wait while the network adaptor gets ready. This will take approximately 20 seconds.



Preparing your projector

iii) When complete, you will see this screen containing your Login Code and SSID. Keep these in mind as they will be important in future steps.



2. Preparing your PC/Mac



Preparing your PC/Mac


i) On your PC or Mac, open a web browser and go to www.support.casio.com

ii) Select 'Downloads'

The screenshot shows the Casio Worldwide Support website. At the top, the Casio logo is on the left, and 'WORLDWIDE' is in the center. On the right, there is a globe icon and the text 'world.casio.com'. Below this is a navigation bar with links: Corporate, News, Investor Relations, Sustainability, and Support. Under the Support link, there is a 'Home >' breadcrumb. The main heading is 'Support'. Below it is a section titled 'International Links' with the text 'Select your local website for product/support information.' This section features a world map with five regions highlighted: North America (blue dot), Latin America (green dot), Europe (pink dot), Middle East & Africa (orange dot), and Asia & Oceania (red dot). Below the map is a 'Technical Support' section with five buttons: 'FAQs' (with a question mark icon), 'Manuals' (with a document icon), 'Downloads' (with a download icon), 'Windows / Mac OS' (with a Windows logo icon), and 'iOS / Android' (with an Apple logo icon). A red arrow points from a red button labeled 'Downloads' at the bottom of the page to the 'Downloads' button in the Technical Support section.

Preparing your PC/Mac

iii) Select projectors



iv) Choose you language



Preparing your PC/Mac

v) Scroll down to Network Connection and click the link, note the first link refers to a windows compatible version of the software. For Mac users, your link is a little further down.

The screenshot shows a web page with a list of software download links. A red arrow points from a 'Windows' button to the first link under 'Network Connection'. Another red arrow points from a 'Mac' button to the first link under the second 'Network Connection' section. A red box highlights the 'for Mac' text in a link.

Network Connection

- ▶ [Network Connection - Jun. 2014](#)

CASIO Projector LOGO Loader

- ▶ [CASIO Projector LOGO Loader Version 1.0.0 - Jul. 2014](#)

CASIO Projector Flash Loader

- ▶ [CASIO Projector Flash Loader Version 1.0.0](#)

PtG2 Converter

- ▶ [PtG2 Converter Version 2.1.0.5](#)

for Mac

wePresent

- ▶ [wePresent for Mac Version 1.1.1.8 - Feb. 2012](#)

Network Connection

- ▶ [Network Connection - Jun. 2014](#)

Preparing your PC/Mac

vi) Scroll to the bottom of the page and select the file download link

6) Follow the instructions that appear on the screen to install Wireless Connection 3.

Conditions Governing Use

Be sure to observe the following conditions that govern use of the Network Connection software (this Software).
You are not allowed to use the Network Connection software unless you agree to observe these conditions governing use.

- 1) You are allowed to use this Software only with the CASIO projector models specified by "Supported Models" above.
- 2) You are not allowed to distribute this Software in any way.
- 3) You are not allowed to reverse engineer, disassemble, decompile, or otherwise reduce the Software to human-readable form.
- 4) You are not allowed to alter the copyright of the Software in any way.
- 5) CASIO COMPUTER CO., LTD. shall not be held responsible for any damages or losses suffered due to the use of this Software.
- 6) You assume all responsibility related to the downloading and use of this Software.

Download File

[ConnectionSoft0025.exe](#) (3,500KB)

Download File link

* For the User's Guide PDF file, click [here](#) and see the list of Supported Models.

To use this function:	Install this driver software:
Extended screen output function	VDD driver (for Windows XP and Windows Vista)

vii) Enter the 16 digit serial number located under the device's barcode and select download file

CASIO

WORLDWIDE

Download

Product Confirmation

The information presented here is for those who have purchased a CASIO Projector.
On the back of your projector you will find a bar code sticker. Enter the 16-digit number under the bar code (*****-*****) into the space provided below.

Number	<input type="text" value="C925EEAY59087236"/>
--------	---

Serial Number

*Enter the number using single-byte characters.
*Input the numbers only. Do not input the hyphen.


Entering a valid number and clicking the [Download File] button will start download.

Download File

Download File

Preparing your PC/Mac

viii) When the download is complete, open the file and follow the prompts to install the software



x) When the installation is successfully completed, this icon will appear on your desktop labelled 'Network Connection'




3. Making the Connection




Making the Connection

i) To connect your PC or Mac to the projector, first connect to the projector's Wi-Fi signal.



Please note the password is: your projectors SSID text, e.g. casiolpj, followed by a 0 and the final number of the SSID, in this case 1.



Example:

SSID = **casiolpj0101**

Wi-Fi Password = **SSID text** + 0 + **last number**

Wi-Fi Password = **casiolpj**+0+**1**


Wi-Fi Password = casiolpj01

Making the Connection

ii) When connected, open the previously installed network connection software




iii) The Passphrase or WEP Key will be automatically populated, simply click OK



Making the Connection

iv) You will be asked for your login code which is displayed in the top left hand corner of your projection




v) Enter the code and click ok



Making the Connection

vi) Your projector will now mirror your computer display



Wirelessly Connect your Mobile Device to your Casio Projector



Wireless Mobile Device Connection

Connecting your Mobile Device to your new Casio Projector via a wireless network is a 3 step process:

1. Preparing your Projector



2. Preparing your Mobile Device



3. Making the Connection



1. Preparing your Projector



Preparing your projector

i) Turn your projector on by connecting the power cord to the back of the unit (A) and pressing the power button (B)




ii) Plug your wireless adaptor into the port on the back of your projector marked USB-A. Please wait while the network adaptor gets ready. This will take approximately 20 seconds.



Preparing your projector

iii) When complete, you will see this screen containing your Login Code and SSID. Keep these in mind as they will be important in future steps.



2. Preparing your Mobile Device



Preparing your Mobile Device

i) Depending on your devices operating system, go to the apple App store or Google Play store and search for C-Assist.



ii) Download the app to your mobile device.

C-Assist







3. Making the Connection




Making the Connection

i) Open your mobile device's settings menu and select wifi.





Making the Connection

ii) Turn on your wifi and select your casio projector





iii) Enter your password and select Connect

Please note the password is: your projectors SSID text, e.g. casioIpj, followed by a 0 and the final number of the SSID, in this case 1.





Making the Connection

iv) When connected, open the C-assist App





v) Select your projector and press select





Making the Connection

vi) Enter your login code and press Login
(code displayed in the top left hand corner of your projection)



vii) You are now connected and able to project files and more via the C-Assist App.



Enabling internet browsing with C-Assist for Android



Enabling Android Internet Browsing

While wirelessly connected to your Casio Projector, your Android device is unable to access any other networks.

This prevents Android devices from browsing the internet while connected to a projector.

By connecting the Casio Projector itself to a local network, we are able to browse the internet AND use our android device to control the projector.

Follow these instructions to learn how to connect your Casio Projector to a local network.




Please note, this issue does not apply to iPhones so these steps do not need to be carried out.

Enabling Android Internet Browsing

i) Connect your Android or PC/Mac to your Casio Projector as outlined in this manual




ii) Open a web browser and, in the address bar enter the server IP found in the bottom left hand corner of your projection




Enabling Android Internet Browsing

iii) You will be connected to your Casio Projector's Network Presentation System




iv) Select Projector Admin



Enabling Android Internet Browsing

v) Enter the password “admin” and select Login



Network Presentation System

CASIO Projector > Projector Admin

Projector Admin
Transfer File
Viewer Control


User Name admin

Password Login

Admin Login

Copyright © 2014 CASIO COMPUTER CO., LTD. All Rights Reserved.

vi) Select Network Settings



Network Presentation System

CASIO Projector > Projector Admin > System Status Logout

System Status
Control Panel
Network Settings
Change Passwords
Initialize Settings
Crestron Control

Model Name	STD_WXGA
Version	
Network Status	
IP Address	10.77.0.158
Subnet Mask	255.255.255.0
Default Gateway	10.77.0.1
Wire MAC Address	08:00:74:67:BA:D6
Wireless MAC Address	08:00:74:68:26:2B
Connection Status	
Projection Status	Projection Standby
Number of Users	0
Login Code	7992


Network Settings

Copyright © 2014 CASIO COMPUTER CO., LTD. All Rights Reserved.

Enabling Android Internet Browsing

v) Enable External Access Point

vi) Select Scan for Access Points

 Network Presentation System

CASIO Projector > Projector Admin > Network Settings Logout

System Status

Control Panel

Network Settings

Change Passwords

Initialize Settings

Crestron Control

IP Settings	<input checked="" type="radio"/> Obtain an IP address automatically <input type="radio"/> Use the IP address below	
	IP Address	192 . 168 . 100 . 10
	Subnet Mask	255 . 255 . 255 . 0
Default Gateway	192 . 168 . 100 . 10	
DHCP Settings	<input checked="" type="radio"/> Auto <input type="radio"/> Disable	
	Starting Address	192 . 168 . 100 . 11
	Ending Address	192 . 168 . 100 . 254
Wireless Settings	Access Point Function	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
	SSID	casiolpj0 101
	SSID Broadcast	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
	Channel	Auto ▼
	Security	WPA-PSK AES ▼
	Passphrase/WEP Key <input checked="" type="checkbox"/> Hide characters
External Access Point	External Access Point	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
	External Access Point SSID	ShriroVisitor Scan Access Point
	Security	WPA2-PSK TKIP ▼
	Passphrase/WEP Key <input checked="" type="checkbox"/> Hide characters

Apply Cancel

Enable

Scan

Enabling Android Internet Browsing

vii) Use the Drop down menu to select a local Wi-Fi network

viii) Ensure the Security type is correct

Network Presentation System

CASIO Projector > Projector Admin > Network Settings Logout

System Status
Control Panel
Network Settings
Change Passwords
Initialize Settings
Crestron Control

IP Settings	<input checked="" type="radio"/> Obtain an IP address automatically <input type="radio"/> Use the IP address below	
	IP Address	192 . 168 . 100 . 10
	Subnet Mask	255 . 255 . 255 . 0
DHCP Settings	<input checked="" type="radio"/> Auto <input type="radio"/> Disable	
	Starting Address	192 . 168 . 100 . 11
	Ending Address	192 . 168 . 100 . 254
Wireless Settings	Access Point Function	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
	SSID	casiolpj0 101
	SSID Broadcast	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
	Channel	Auto ▼
	Security	WPA-PSK AES ▼
	Passphrase/WEP Key <input checked="" type="checkbox"/> Hide characters
	External Access Point	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
External Access Point	External Access Point SSID	Select an access point: ▼ Scan Access Point
	Security	WPA2-PSK TKIP ▼
	Passphrase/WEP Key <input checked="" type="checkbox"/> Hide characters

Drop Down Menu


Security Type

Save Cancel

Enabling Android Internet Browsing

ix) Enter the Wi-Fi password

x) Select Apply

 Network Presentation System

CASIO Projector > Projector Admin > Network Settings Logout

System Status
Control Panel
Network Settings
Change Passwords
Initialize Settings
Crestron Control

IP Settings	<input checked="" type="radio"/> Obtain an IP address automatically <input type="radio"/> Use the IP address below	
	IP Address	192 . 168 . 100 . 10
	Subnet Mask	255 . 255 . 255 . 0
	Default Gateway	192 . 168 . 100 . 10
DHCP Settings	<input checked="" type="radio"/> Auto <input type="radio"/> Disable	
	Starting Address	192 . 168 . 100 . 11
	Ending Address	192 . 168 . 100 . 254
Wireless Settings	Access Point Function <input checked="" type="radio"/> Enable <input type="radio"/> Disable	
	SSID	casiolpj0 101
	SSID Broadcast	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
	Channel	Auto ▼
	Security	WPA-PSK AES ▼
	Passphrase/WEP Key <input checked="" type="checkbox"/> Hide characters
External Access Point	External Access Point SSID External Access Point <input checked="" type="radio"/> Enable <input type="radio"/> Disable Select an access point: ▼ Scan Access Point	
	Security	WPA2-PSK TKIP ▼
	Passphrase/WEP Key <input checked="" type="checkbox"/> Hide characters
<div>Apply Cancel</div>		

Password

Apply

Enabling Android Internet Browsing


- xi) When you select apply the projector will restart
- xii) Reconnect to your Casio Projector using your Android device as detailed in this manual.

By connecting the Casio Projector itself to a local network, we are now able to browse the internet AND use our android device to control the projector.




Connecting your Mobile Device to your Casio Projector

- 1) Plug in your projector and turn it on with the power button
- 2) Plug the wireless adaptor into the USB-A slot
- 3) Make a note of the projected SSID and Login Code



- 4) Download the C-Assist App from the iTunes or Google Play Store



- 5) Open your mobile device's settings menu and select Wi-Fi
- 6) Turn on your Wi-Fi and select your Casio projector



7) Enter the following password and select Connect:

SSID = **casiolpj0101**


Wi-Fi Password = **SSID text** + 0 + **last number**

Wi-Fi Password = **casiolpj+0+1**


Wi-Fi Password = **casiolpj01**

8) Open the C-assist App

9) Select your projector and press Select



10) Enter your login code and press Login




11) You are now able to project files and more via the C-Assist App

Connecting your Casio Projector to Wi-Fi internet


*Required to browse the internet while projecting from an Android device only. This is not necessary when using an iOS device

- 1) Connect your Android or PC/Mac to your Casio Projector (see manual)
- 2) In a web browser go to the Server IP found in the bottom left hand corner of your projection




E.g.: 192.168.100.10

- 3) Select Projector Admin



Projector Admin

- 4) Enter the password "admin" and select Login
- 5) Select Network Settings



Network Settings



Network Presentation System

CASIO Projector > Projector Admin > Network Settings

Logout

System Status

Control Panel

Network Settings

Change Passwords

Initialize Settings

Crestron Control

IP Settings

- ☒ Obtain an IP address automatically
☐ Use the IP address below

IP Address: 192 . 168 . 100 . 10

Subnet Mask: 255 . 255 . 255 . 0

Default Gateway: 192 . 168 . 100 . 10

DHCP Settings

- ☒ Auto ☐ Disable

Starting Address: 192 . 168 . 100 . 11

Ending Address: 192 . 168 . 100 . 254

Wireless Settings

- Access Point Function: ☒ Enable ☐ Disable

SSID: casiolpj0
101

SSID Broadcast: ☒ Enable ☐ Disable

Channel: Auto

WPA-PSK AES

.....

☒ Hide characters

External Access Point

- ☒ Enable
☐ Disable

External Access Point SSID

Select an access point: ▼

Scan Access Point

Security

WPA2-PSK TKIP

Passphrase/WEK
Key

.....

☒ Hide characters

Apply Cancel

7) Click Scan Access Point

6) Click Enable

8) Select Wi-Fi from drop down menu

9) Select Wi-Fi security type

10) Enter password

11) Select Apply



12) When you select 'Apply' your Projector will restart

13) Once restarted, reconnect to your Casio Projector using your Android device as detailed in this manual.


14) By connecting the Casio Projector itself to Wi-Fi, we are now able to browse the internet AND use our android device to control the projector.

Connecting your PC/Mac to your Casio Projector

- 1) Plug in your projector and turn it on with the power button
- 2) Plug the wireless adaptor into the USB-A slot
- 3) Make a note of the projected SSID and Login Code



- 4) Go to world.casio.com/download/projector/, select your language, then download and install the Network Connection software




5) Connect your PC/Mac to the projector's Wi-Fi signal. The password is as follows:

SSID = **casiolpj0101**

Wi-Fi Password = **SSID text** + 0 + **last number**

Wi-Fi Password = **casiolpj+0+1**

Wi-Fi Password = **casiolpj01**




6) Open the Network Connection software



7) The Passphrase/WEP Key will be automatically populated, click OK



8) Enter your Login code and click OK



9) Your monitor will be displayed by your Casio Projector

