

SeKi

Slim



Programming

Step 1

Press POWER and CH UP buttons at the same time. The LED will start flickering constantly.

The learning system is on now.

Step 2

Hold the sending end of the established remote aiming at the receiving end of SeKi. (distance 2-5cm)

Step 3

Press the button of SeKi remote control (such as POWER button) until the LED remains on.

Step 4

Hold down the button of the original remote control (such as POWER button). When receiving the correct data, LED will be flickering 2 times slowly and then turn into flickering constantly. At this time please stop holding the button.



Step 5

To learn other buttons repeat steps 3 + 4 until the end of all learning.

Step 6

When learning is completed, press POWER and CH UP button again to exit learning state.

The LED will extinguish.

You are done and can now use your SeKi.

Copy button for button



www.my-seki.de