

**ONE**<sup>®</sup>  
**FOR ALL**

# Instruction manual



**URC-1669**

**ONE**  
**FOR ALL**

# Introduction

Congratulations on the purchase of the URC-1669. The URC-1669 is a replacement remote control that can be set up to control 2 devices.

- **sat** - Satellite Receiver, Digital Box or Cable Box
- **tv** - Television, Plasma- or LCD TV

**The URC-1669 is preprogrammed to control your Foxtel iQ Box (no set up required). Simply press the "sat" device key and your will obtain Foxtel iQ Box functionality.**

## Table of Contents

<b>THE KEYPAD</b>	3
-------------------	---

<b>SET UP</b>	
<b>SETTING UP THE URC-1669</b>	<b>5</b>
Direct code set up	5
Search Method	6
<b>SET-UP CODES</b>	
<b>TV</b> : Television / LCD / Plasma / Projector / Rear Projector . . . . .	10
<b>SAT</b> : Satellite Receiver / Set-Top-Box / DVB-S / DVB-T / Freeview (UK) / TNT (F) / Digitenne (NL) / SAT/HDD . . . . .	17
<b>CBL</b> : Cable Converter / Set-Top-Box / DVB-C . . . . .	22
<b>VAC</b> : Video Accessory like Media Centres / AV Accessories / AV Selectors . . . . .	23

<b>CODE BLINK OUT</b> (To find out which code is currently programmed)	7
---	---

<b>QUICK CODE REFERENCE</b>	7
-----------------------------	---

<b>EXTRA FEATURE</b> • Volume Punch-Through	8
--	---

<b>TROUBLE-SHOOTING</b>	9
-------------------------	---













<b>CUSTOMER SERVICE</b>	9
-------------------------	---












## Installing the Batteries

Your URC-1669 needs 2 new "AA/LR6" alkaline batteries.

- 1 Remove the battery cover from the back of your URC-1669.
- 2 Match the batteries to the + and - marks inside the battery case, then insert the batteries.
- 3 Press the battery cover back into place.

# The Keypad

- 1**  **Power**  
The POWER key operates the same function it did on the original remote control.
- 3**  **sat (LED) - device key for:**  
Satellite Receiver, Cable Converter, DSS / Video Accessory (e.g. Media Centres) Personal Video Recorder or Hard Disc Recorder.  
*The red LED (Light Emitting Diode) underneath the sat key will light up every time a key is pressed in sat mode.*  
**As default: when in "sat" mode your URC-1669 will be set to control your Foxtel iQ Box.**
- 2**  **tv (LED) - device key for:**  
Television, LCD, Plasma, Projector or Rear Projector. *The red LED (Light Emitting Diode) underneath the tv key will light up every time a key is pressed in tv mode.*
- 4**  **tv guide**  
This key gives you the possibility to preview the complete tv listings.
- 5**  **box office**  
This key allows you to access the Box Office programs.
- 6**  **services (setup)**  
Displays the Setup screen where you can change the set-top unit's settings. This key provides a range of features such as e.g. parental controls, subtitles and favourites. For your particular device this key may provide menu control.
- 7**  **interactive (active)**  
This key provides a selection of interactive services.
- 8**  **volume +/- Keys**  
These keys operate in the same way as the keys on your original remote. *In "tv" mode you may obtain Colour + / - when you press and release the magic key and then press Volume + / - .*
- 9**  **channel +/- Keys**  
These keys operate in the same way as the keys on your original remote. *In "tv" mode you may obtain Brightness + / - when you press and release the magic key and then press Channel + / - .*
- 10**  **Directional Keys**  
If available on your original remote, these keys will allow you to navigate through the menu mode of your device.
- 11**  **select**  
The select key will confirm your choice in the corresponding menu.
- 12**  **Mute Key**  
The Mute key operates the same function it did on your original remote control.

- 13**  **i (info) Key**  
This key provides information about the program you're watching.
- 14**  **back up Key**  
This key allows you to go back to the previous page.
- 15**  **text**  
Puts the television in the Teletext mode.
- 16**  **text off**  
Switches the television back to regular viewing mode. On some televisions, this may be done by pressing the text key several times.
- 17**  **16:9**  
This key provides you the (16:9) wide screen view function, if available on your original remote).
- 18**  **help / FOXTEL**  
Takes you back to the last channel being watched on Foxtel, also returns the remote from "AV" mode back to "Foxtel".
- 19**  **Transport Keys**  
If available these keys operate the transport functions (PLAY,FF, REW etc.) of your Foxtel iQ Box / Satellite Receiver / Set Top Box / Cable Box. To prevent accidental recording, the RECORD key must be pressed twice to start recording.
- 19**  **red, green, yellow, blue**  
After pressing the tv key and accessing the text mode, the keys marked red, green, yellow and blue, allow you to access the Fastext functions of your television. If on your original remote control these keys are used for Menu navigation, the ONE FOR ALL Fastext keys may operate in the same way.
- 20**  **Number Keys**  
The Number keys (0-9, / -/--) provide functions just like your original remote. If your original remote has an 20 key, this function can be found under the AV key.
- 21**  **magic Key**  
The magic key is used to set up your URC-1669.
- 22**  **tv/sat Key**  
In tv mode you will obtain the AV / Input function. In sat mode you will obtain the "TV/SAT" or "TV/DTV" function, if available on your original remote.







**Please note that the key pad description is mainly based on Foxtel iQ Box functionality. This may differ from your particular device.**

# Setting up the URC-1669

Before you start, please read these instructions carefully

## Direct code set up

**Example: To set up the URC-1669 for your television:**

-  Find the code for your device in the Code list (page **10 - 23**). Codes are listed by device type and brand name. The most popular code is listed first. **Make sure your device is switched on (not on standby).**
-  Press the **tv key** on the URC-1669 for the device you wish to Set-Up.
-  Press and **hold down** the **magic key** until the red LED underneath the tv key blinks twice (the red LED will blink once then twice). 
-  Enter your **(four-digit device code)** using the number keys. The red LED will blink twice.
-  Now, aim the URC-1669 at your device and **press POWER** if your device switches off, the **URC-1669 is ready to operate your device.**
- Turn your device back on and try all the remote's functions to ensure they are working properly. If the functions do not work properly, repeat steps 1-5 using another code listed under your brand.
- If your device does not respond, follow steps 1 to 5 with each code listed for your brand. If none of the codes listed for your brand operate your device, or if your brand is not listed at all, try the search method described on page 6.**

### Important notes:


- If your Set Top Box is not a standard Foxtel iQ Box, please follow the steps above pressing "sat" instead of "tv" during step 2.
- Most Televisions do not switch on pressing the POWER key. Please try pressing a "number" key or the "TV-text off" key to switch your TV back on.
- Some codes are quite similar. If your device does not respond or is not functioning properly with one of the codes, try another code listed under your brand.
- CBL and VAC codes can be set up in "sat" mode.
- Remember to press the correct device key before operating your device.


## The Search Method

If your device does not respond to the URC-1669 after you have tried all the codes listed for your brand, try searching for your code. The Search Method allows you to find the code for your device by scanning through all the codes contained in the memory of the URC-1669. The Search Method may also work if your brand is not listed at all.

### Example: To search for your TV code:


1 Switch your television on (not on standby) and aim your ONE FOR ALL at your TV.


2  Press the **tv key** on your URC-1669.


3  Press and **hold down** the **magic key** until the red LED underneath the POWER key blinks twice (the red LED will blink once then twice).



4    Press **9 9 1**. The red LED will blink twice.

5  Next, press **POWER**.

6  Aim the URC-1669 at your Television. Now press **CH+** over and over, until your Television turns off (everytime you press the CH+ key the URC-1669 will send out a POWER signal from the next code contained in the memory). You may have to press this key many times (up to 150 times) so please be patient. If you skip past a code, you can go to the previous code(s) by pressing the CH- key. Remember to keep pointing the URC-1669 at your Television while pressing this key.

7  As soon as your television turns off, press the **MAGIC key** to store the code.

#### Important notes:











- If your Set Top Box is not a standard Foxtel iQ Box, please follow the steps above pressing "sat" instead of "tv" during step 2.
- Most Televisions do not switch on pressing the POWER key. Please try pressing a "number" key or the "TV-text off" key to switch your TV back on.
- To search for the code for another device follow the instructions above only press the appropriate device key instead of TV during step 2.

# Code Blink out

(To find out which code is currently programmed)

Once you have Set-Up your URC-1669, you can blink back your SET-UP CODE for future reference.

Example: To blink out your Television code:

-  Press **tv** once.
-  Press and **hold down** the **magic key** until the red LED underneath the POWER key blinks twice (the red LED will blink once then twice). 
-    Press **9 9 0**. The red LED underneath the POWER key will blink twice.
-  For the first digit **of your four-digit** code, press **1** and count all the red blinks. If there are no blinks, the digit is "0".
-  For the second digit, press **2** and count all the red blinks. If there are no blinks, the digit is "0".
-  For the third digit, press **3** and count all the red blinks. If there are no blinks, the digit is "0".
-  For the fourth digit, press **4** and count all the red blinks. If there are no blinks, the digit is "0". **Now you have your four-digit code.**

## Important notes:

- If your Set Top Box is not a standard Foxtel iQ Box, please follow the steps above pressing "sat" instead of "tv" during step 2 to blink out the code programmed in "sat" mode.

## Quick Code Reference

Device

Code

sat \_\_\_\_\_

--	--	--	--






tv \_\_\_\_\_

--	--	--	--






## Volume Punch Through

When controlling your Set-Top-Box (e.g. Foxtel iQ Box) you normally need to press the "tv" button first if you wish to control the volume for your Television. The URC-1669 gives you the possibility to punch through TV-VOLUME without pressing the tv mode key. This is only possible if you have programmed the URC-1669 to also control your Television.

### To punch through to TV volume while in "sat" mode:

-  **Press and hold down the magic key until the red LED underneath the POWER key blinks twice (the red LED will blink once then twice).**
-    Press **9 9 3**.
-  Then press the tv key and the red light will blink twice.

### To cancel the "Volume Punch Through":

-  **Press and hold down the magic key until the red LED underneath the POWER key blinks twice (the red LED will blink once then twice).**
-    Press **9 9 3**.
-  Press the Volume (+) key and the red light will blink four times.



## Problem & Solution

<b>Problem:</b>	<b>Solution:</b>
Your brand is not listed in the code section?	Try the search method on page 6.
The ONE FOR ALL does not operate your device(s)?	A) Try all the codes listed for your brand. B) Try the search method on page 6.
The ONE FOR ALL is not performing commands properly?	You may be using the wrong code. Try repeating the Direct Set-Up using another code listed under your brand or start the search method over again to locate the proper code.
Problems changing channels?	Enter the programme number exactly as you would on your original remote.
The ONE FOR ALL does not respond after pressing a key?	Make sure you are using new batteries and are aiming the one for all at your device.
The red LED does not blink when you press a key?	Replace batteries with 2 fresh, new "AA" alkaline batteries.

## Customer Service

### **Australia**

1 300 888 298

[ofa.support@ambertech.com.au](mailto:ofa.support@ambertech.com.au)

[www.ambertech.com.au](http://www.ambertech.com.au)

[www.oneforall.com](http://www.oneforall.com)

# TV

A.R. Systems	0037 0373 0556
Accent	0037 0556
Accusound	0860
Acentic	0556
Acer	1339
Acoustic Solutions	1667 1727 1545 1585 1523 1865 1037 1163
Adcom	0625
Admiral	0093 0264
Advent	1613
AEA	0037 0556
AEG	0606 1556 1324 1037 1667 1163 1585 2239 2197 2241
Aftron	0891
Agashi	0264
Agfaphoto	2239
Agora	1585 0037
Aiko	0037 0556 0371 0035 1681 0880 0361 0191 0264
Aim	0037 0556 0753 0208 0706 0698 0634 0606 0499
Airis	1833 0556
Aiwa	0701 1916 1505
Akai	0361 1326 2197 0208 0371 0037 0191 0035 0753 0806 0714 0706 0698 0715 0556 0480 0264 0178 0606 1037 0473 0812 1248 1727 1308 1865 1163 1523 1652
Akashi	0860
Akiba	0037 0556
Akira	2241 0753 0037
Akito	0037 0556
Akura	1770 1687 0714 1709 1667 1037 0037 0556 1645 0668 1585 0264 1982 1983 1363 2239 2059
Alba	1037 1585 0714 0037 1997 0668 0556 0371 0587 0487 0443 2007 1865 1163 2214 1667
Alios	2168
Alkos	0035
Allstar	0037 0556
All-Tel	0865
Amitech	1849
Amstrad	1667 1163 0264 0371 0037 0556 1037 1324 1982
Anam	0037 0556 0650
Anam National	0037 0650 0556
Andersson	1163 1667 1585 0037 0264
Anglo	0264 0037 0556
Anitech	0264 0037 0556
Ansonic	1582 0037 0556 0668 0292
AOC	0625 1588 2111 2214
Apollo	0473
AquaVision	1606
Arc en Ciel	0109
Arçelik	0714 2125 0037 1308
arctic	1652
Ardem	0486 0714 0037 0633 0556 0715
Arena	0037
Aristona	0556 0037
ART	1037
Art Mito	1585 1667
Asberg	0037 0556
Astra	0037 0556
Asuka	0264
ATD	0698 0706
Atec	1606
Atlantic	0037 0556
Audiosonic	0037 0820 0556 0109 1308 1681 0714 0715 2059 0264 0486 1983
Audioton	0486 0264
Audioworld	0698 0706
Autovox	1163 1585 1667
AWA	2241 0037 0698 0178 0556 0606 0108 0264 1681 3296
Axxon	0714
Azuki	2239
Baier	1324 2239
Baird	0109 0343 0208 0606
Bang & Olufsen	0565 0620
Base	0780 0698
Basic Line	1667 1163 0037 0668 0556 1037
Bauer	2197 0698 0706 0264
Bauhn	2461
Baur	0535 0195 0512 0037 0556 0191 0361 1505
BBK	1523 1645
Beaumarck	0178
Beko	0714 0486 0035 0715 0037 1308 0556 0606 0808 1652 2125
Belson	0698 0706 2241 2032 3296 1667
Belstar	1037
Bennett	0556 0037
BenQ	1562 1523 2214
Bensten	1326 1413
Beon	0037 0556
Beond	1833
Berthen	0668 0556
Bestar	0037 0556
Bestwell	1326
Black Diamond	0820 1037 0556 0753 1163 0587
Black Strip	0035
Blaupunkt	1709 2106 0195 0191 0535 0170
Blu:sens	1849 2241
Blue Media	1606
Blue Sky	0037 1324 1037 0714 1709 1667 0487 0668 0715 0625 1652 0624 0556 0808 1363 1916
BlueDiamond	2106
Blush	1775 1709
Boca	1652
Boman	1324
Bork	1363
BPL	0037 0556 0373
Brandt	0625 0109 0287 0335 0343 0560 1585 1667
Brandt	Electronique 0287 0335
Brimax	1709
Brinkmann	0037 0556 0668 0486
Brionvega	0037 0556
Brother	0264
Bruns	0486
BSR	0361

Bush	1037 2032 1326 1585	Deitron	0037 0556
	2214 2125 1667 0371	Denko	0264
	1556 0714 0037 0668	Denver	0037 1324 0556 0606
	1916 1652 0264 0361		0587 1849 2239 1709
	0487 0208 0698 0706		2139 2197 1770
	0556 1982 1248 1682	Desmet	0037 0556
	0587 1687 1308 2053	Dew	1770
	1983 2241 2239 1865	DGM	2239 2059
	1720 0443 2007 2059	Diamant	0037 0556
	2223 1645	Diamond	0264 0698 0371 0860
Cameron	1523 0556		0820 0896 1681 0706
Camper	0037 0556 0486	DiBoss	0037 0556
Capsonic	0264	Dick Smith	
Carad	0610 0037 0556 0668	Electronics	1326 2241 3296
	1037	Digatron	0037 0556
Carena	0037 0556	Digihome	1667 1163
Carrefour	0037 0556	Digiline	0037 0556 0668
Carver	0170	DigiLogic	0037 0556 1997
Cascade	0037 0556	Digimate	2239
Casio	0037 0556	DigiMax	0891
CAT	1682	Digital Device	1606
Cathay	0037 1727 0556	Digitek	1709
CCE	0037 0556	Digitex	0820
Celcus	1163 1667 1585 0037	Digitor	0037 0556 0888 0698
	1037		0706
Celestial	0820	Digivision	0361
cello	1770	DigiX	0880
Centrex	0780 0891 0698 1702	DiK	0037 0556
Centrum	1037	diVision	2197
Centurion	0037 0556	Dixi	0037 0556
CGE	0074	DL	0891 0780 0037 0587
Changhong	3296		0865 1363 1326
Chimei	1666	DMTECH	1163 1849 2001 2223
Cinex	1556 1982	Domeos	0668 0037 1037
Clarity	1720	DSE	0698 0888 1556 0820
Clarivox	0037 0556		0706 1682 2241 2032
Clatronic	0037 0371 0714 0264		2098 1326 3296
	0556 0606 1324 1163	Dual	0343 0037 0556 1137
Clayton	1037		1667 1037 2032 2241
CMX	3296		1324 1163 1585 0714
Cobolt	0891		2197
Condor	0037 0556 0264	Durabrand	0037 0556 1652 1037
Conia	1687 0754 1645 2032		0714
	0820 1702 1523	Dux	0037 0556
Conrac	0808	D-Vision	0037 1982 2197 2239
Conrad	0037 0556		0556
Contec	0264 0037 0556	DVX	0891
Continental		Dynatron	0037 0556
Edison	0109 2241 0287 0487	Dyon	2241
Cosmel	0037 0556	E.S.C.	0037 0556
CPTEC	0625 1363	e:max	1324 0606
Crosley	0074	Easy Living	1248 1709 1613 1308
Crown	0712 0486 0037 0556		2005 2007 1556 1666
	0487 0714 0606 0715	Easy Touch	2059
	0373 0208 0653 1037	Ecco	0706 0698
	1652 0668	ECG	2197 2239 2125 0037
Curtis Mathes	0093		1037
CWR-Tech	1324	Edison-Minerva	0487
Cyberpix	1667	Elbe	0610 0292 0037 0556
Cytronix	1298		0191 0361
D.Boss	0037	Electrion	1585
Daewoo	0634 1849 2098 2125	Elekta	0037 0556 0264
	0661 0499 0624 0037	Elfunk	1208 1037
	0556 1137 0880 0865	ELG	0037 0556
	0698 0714 0706 2037	Elin	0037 0556 0361
Dansai	0037 0556 0264 0035	Elite	0037 0556
	0208	Elonex	1776
Dantax	0486 1652 1916 0714	Elta	0264
	1037 0606 0715	Emerson	0714 0178 0037 0556
Datron	0625		0371 0361 0624 0486
Datsura	0373 0208		0668
Dawa	0037 0556	e-motion	0865 1709 2106
Daytek	0698 0706 0264	Enzer	0753 0860
Daytron	0037 0556	Erisson	1682
de Graaf	0208	Erres	0037 0556
DEC	0860 0891 1326 0896	Etron	0037 0556 0820
Decca	0037 0556 1137	Eurofeel	0264

EuroLine	0037	Goodmans	0634 1248 2393 1667
Euroman	0264 0037 0556		1795 1585 1687 1037
Europa	0037 0556		0624 1983 0037 0499
Europhon	0037 0556		0556 1916 0714 0668
Eurovision	1163 1667		1163 0264 0487 0371
Evesham	1667 1248 1606		0343 0035 0480 0560
Excel	0037 0556		0335 0661 0880 1308
Excello	1037		0587 1727 1645 1682
Exquisit	0037 0556		1720 2053 2223 1523
Fagor	0037 0556		1709 0808 1997 2214
Family Life	0037 0556	Gorenje	1585 1667
Fenner	1667 1163	GP	0753
Ferguson	0625 0335 1037 0287	Gradiente	0653 0170 0037 0556
	0109 0560 0343 2393	Graetz	0714 0361 0371 0037
	0037 0556 0035 0653		0556 1163 1585 1667
	0108 0361 0443 2007	Gran Prix	2197
	1916 2053 1865 2106	Granada	0037 0556 0226 0108
Fidelity	0512 0037 0556 0371		0208 0473 0335 0560
	0264 0361		0343
Finlandia	0208 0361 0287 0343	Grandin	1652 0037 0556 0610
Finlux	0037 0556 0714 1585		0714 0715 0668 1037
	1667 0715 0480 1556		0865 0880 2125
	0473 0606 0808 1248	Grundig	0195 0508 1223 2059
	1163		3296 2239 2125 1582
Fintec	1982		0443 0191 1687 0535
Firstline	0037 0556 0668 0714		1037 0487 0037 2007
	0624 0208 0361 1037		0706 0556 0587 1916
	0808 1363 1163 1308		1308 0178 0343 1667
	0208 0361		2053 1324 1645 1523
Fisher	0037 0556 0610 0264	Grunkel	1163 1523
Flint	0178	GVA	1326 2098 2037
Foehn & Hirsch	1667	H&B	0808 2001
Force	0037 0556 0486	Haaz	0706
Formenti	0093	Haier	0698 0264 0706 2214
Fortress	0037 0556		2241
Fraba	1636	Halifax	0264
Freesat	0037 0556 0499 0610	Hammerstein	0264
Friac	0264	Hanns.G	1613
Frontech	0780	Hannspree	1351 1613 1776 2214
Fuchsware	1709	Hanseatic	0037 0556 0499 0361
Fujicom	0865		0292 0634 0661 0373
Fujimaro	0853 0037 0556 0361		0714 0808 0486 0625
Fujitsu	1666 1298 1248 1163		2001
Fujitsu Siemens	0808	Hantarex	2197 0037 0556 0865
	1817 1394 1037 1666	Hantor	0037 0556
	1595 0668 0264 1505	Harsper	0865
	0714 1652	Harwood	0037 0556 0487
Funai	0860	Hauppauge	0037 0556
	0264 0860 0698	HB	1324
Furichi	0037 0556	HCM	0037 0556 0264
Futronic	1037 0037	Hedzon	0556 0037
Future	0037 0556 0361	Hicon	1298
Gaba	0037 0556	Hifivox	0109
Galaxi	0556	Highline	0264 0037 0556
Galaxis	0343 0178 0560 0287	Hikona	1983
Garza	0109 0335 0625	Hinari	0208 0037 0556 0443
GE	0361 0037 0556		2007 0487 0264
	0109 0287	Hisawa	0610 0714
GEC	0343 0287	Hisense	1363 2341 2098 0208
General	0037 0556		2037 0698 0891 0860
General Electric	0037 0556		0780
Genesis	0865 1606 1298 0880	Hitachi	1576 2207 1772 1585
Genexxa	0808		0481 0578 0108 1667
Gericom	1681 1363		0744 1037 1687 0634
	1163 1667 0037 1037		0473 0343 2214 1163
G-Hanz	1585		0499 2005 2007 0480
GoGen	1833 1770		0443 0037 0556 0109
	0668		0178 1137 0361
Gold	0037 0178 0556 0361	Hitachi Fujian	0108 0037 0556 0860
Goldfunk	0109 0606 0714 0715		0499
GoldStar	0487	Hitsu	0610
Gooding		Höher	0714 1556 0865 1163
		Home Electronics	0606
		Horizont	1617
		Hornophon	0037 0556
		Hugoson	1666
		Humax	1295 1539

Hypersonic	0361	Konka	0037 0556 0371 0714
Hypson	0037 0556 0714 0715		0587 0754 0606
	0264 1037 0668 0486	Kontakt	0487
Hyundai	0860 0037 0556 2139	Korpel	0037 0556
	0698 1326 0753 1681	Kosmos	0037 0556
	1770 0264 0888 1037	Kotron	0264
	0865 1606 0706 1556	Küppersbusch	0037 1667
	1163	Kuro	0373
Iberia	0037 0556	Kyoshu	0264
ICE	0264 0037 0371 0556	L&S Electronic	0865 0714
Ict	0037 1137 0556	LaSAT	0486
Ideal	1556	Lavis	1037 0037
IISonic	1613	Lecson	0037 0556
Imperial	0037 0074 0508 0556	Lenco	0037 0556 0587 1037
	2197 0361		1983
Indiana	0037 0556	Levis Austria	0037 0556
Ingelen	0487 0610 0714 0361	Leyco	0264 0037 0556
Ingo Devices	2239	LG	2182 1423 1663 0178
Inno Hit	1037 1667 0037 1308		0037 1305 1842 0714
	0556 1163 1585		1637 0606 0556 0715
Innovation	0037 0556		1681 0698 0706 1859
Innowert	0865 1298		1667
Inotech	0820	Liesenkötter	0037 0556
Inspira	1324 1556	Lifefec	0037 0668 1037 1137
Interactive	0037 0556 0512 0361		2001 0512 0556 0714
	0109		0264 1248
Interbuy	0037 0264 0512 0556	Linetech	1163
Interfunk	0037 0556 0512 0361	Linsar	1585 1667 1163 1037
	0109	Lodos	1037 1667
Internal	0037 0556 0624 0499	Loewe	0512 0633 1884 0292
Intervision	0037 0371 0486 0487		0556
	0264 0556	Logik	0698 0706 1865 1037
Irradio	0037 0556 0371 0714		0880 0264 1585 1702
Isis	1163 1037		1687 1645 2241 0037
Isukai	0037 0556		0371
ITS	0037 0371 0264 0556	Logix	0668
ITT	2125 0480 0361 0473	Luker	1982
	0208 0610 1523 1163	Luma	0037 0556
ITT Nokia	0361 0473 0480 0208	Lumatron	0037 0556 0361 0264
	0606 0610	Lumenio	0037
ITV	0037 0264 0556	Lux May	0037 0556
Jay-tech	2239	Luxor	0480 0361 0208 0473
JDV	1982		1037 1667 1163
JEC	0035	LXI	0178
JGC	1709	Madison	0037 0556
JMB	0037 0499 0634 0556	MAG	2239
	0443 2007	Magnavox	0037 0556 0780 0753
JNC	1702 0896	Magnum	0714 0037 0556 0715
Jocel	0712		1556
JTV	0860	Mandor	0264
Jubilee	0556	Manesth	0037 0556 0264 0035
JVC	0653 1795 1818 1163	Manhattan	0037 0556 0668 1037
	2118 0606 1653 0371	Manta	1702
	0093 0650 3296 2005	Maqma	1298 1702 1709 1606
Kaisui	0037 0556	Marantz	0037 0556
Kambrook	0264	Mark	0037 0556 0714 0715
Kapsch	0361	Marks & Spencer	1770
Karcher	0037 0556 0610 0264	Mascom	1556 0556 0037 2125
	0714 1556 0606 1982		1585 2197
	2125 1308	Mastec	1997
Kathrein	0556 0037 0880	Master's	0499 0037
Kawa	0371	Masuda	0371 0264 0037 0556
Kendo	0037 0610 0556 0512	Matsui	1163 0443 1037 2007
	1585 1037 0486 1667		1916 0037 0195 0556
	1163 1137		0487 0371 0035 0208
Kenmark	2393		0191 0335 0714 1666
Kennex	1037		0880 1667 0744
Keydo	1702	Matsushita	0650
Keymat	1326 1413	Matsuyama	0587
Kingsbrook	1037	Maxam	0264
Kiota	0371	Maxdorf	0698 0706 0264
Kiton	0556 0037 0668	Maxim	1982 1556
Kneissel	0037 0610 0499 0556	Mediator	0037 0556
	0292		
Kobra	1298		
Kolster	0037 0556		

Medion	0714 0808 0037 0668 0556 0512 2239 1137 0698 0706 1037 1248 0880 1916 1556 1667 2001 1849 1163	Nikkai	0037 0556 0264 0035 1667
Megas	0610	Nikkei	0714 2197 1585 1667
Megatron	0178	Nikko	0178
MEI	1037 0037 0556	Nintaus	0891
Melectronic	0037 0512 0109 0343 0480 0287 0556 0624 0634 0361 0191 0195 0661 0714 1652	Nogamatic	0109
Memorex	0178 0650	Nokia	0361 0480 0473 0208 0606 0610 0109
Memory	1983	Nordmende	0560 0891 0109 0287 2001 0343 0195 0037 0556 0335 1248 0714 1413 0443 2007 1585 1667 1163 1308 0625
Mercury	0037 0698 0264 0556 0706	Normerel	0037 0556
Merritt	0361	Nortek	0668
Metz	1533 0746 0447 1163 0195 0535 0191 0037 0556 0587 0668 1037 1637	Novak	0037 0556
MGA	0178 0037 0556	Novatronic	0037 0556
Micromaxx	0037 0556 0668 1037 0808 1324 2001 0714	Novex	1523
Microspot	1614	Novita	1585
Microstar	0808	Nurnberg	0361
MicroTEK	0820 0698 0860 0706 0264	Nu-Tec	0698 0820 0037 0556 0706 0264
Mikomi	1667 1163 0744 1585 0037	O.K.Line	1037 1324 1556
Minato	0037 0556	Oceanic	0361 0208 0473 0480 2001
Minerva	1248 0487 0535 0195 0191 0108	Odeon	0264
Ministry of Sound	1667	Odys	1795 2239 2241
Minoka	0037 0556	OK.	2239
Mirai	1666 1852 1651 1505	Okano	0037 0556 0264
Mitsai	1556	OKI	1037 2125 1667 1585 1308 1163
Mitsubishi	0108 0512 0093 0178 0037 0535 0556 0208 1037	Ölevia	1588
Mivar	0609 0292	Omega	0264
Moree	0037	Omni	0780 0891 0698 0706
Morgan's	0037 0556	Oni	1667
Motorola	0093	Onimax	0714
mp man	3296	Onix	0698 0706
MTC	0512 0361	Onn	1709 1556 1667 2125 0556 1770
MTlogic	0714 1308	Onwa	0371
Multitec	0037 0556 0486 0668 1037 1556 1982	Onyx	1709 1770
Multitech	0486 0037 0556 0264	Opera	0037 1308 0556 0714 1585
Murphy	2005 1849 0443 2007 1667 1163	Optimus	0650
Musikland	0037 0556	Optonica	0093
Mx Onda	1687 1983 1645	Orava	1037 1667 1163
MyCom	0178	Orbit	0037 0556
Myryad	0556 0037	Orbitech	2422
Mystery	3296	Orion	2007 2032 2005 0037 0443 0714 2108 0556 0264 1916 0880 2001 1037 0808
NAD	0178 0865 0361	Orline	0037 0556
Naiko	0037 1982 0606 0556	Ormond	0668 1037 0037 0556
Nakimura	0037 0556	Osaki	0264 0037 0556
Narita	1982	Osio	0037 0556
NAT	0226	Osume	0037 0556
National	0226	OTIC	1687 1645 1983
NEC	0170 2461 0587 1367 1775 0037 0556 0499 0653 0661	Otto Versand	1505 0093 0512 0037 0556 0535 0195 0191 0361 0109 0226 0343 0373
Neckermann	0037 0191 1505 0556 0512	Pacific	0037 1916 0556 1137 0714 1037 0443 1324 2007
NEI	0037 0556 0371 1037	Palladium	0037 0714 1137 0191 1505 0556 1982
NEO	0754 1324	Palsonic	0698 2461 0264 0037 0706 0556 1326 1681 1795
Neon	1770 0753	Panache	1585
Neovia	0865	Panama	0264 0037 0556
Netsat	0037 0556	Panasonic	1636 0650 1650 0226 0361 0853 0037 0556 0108
Neufunk	0037 0556 0610 0714	Panavision	0037 0556
New Tech	0037 0556 0343	Papouw	0037 0556
Nikai	1163		

Pathe Cinema 0292  
 Pathe Marconi 0109  
 Perdio 0037 0556  
 Perfekt 0037 0556  
 Philco 0074 0037 0556  
 Philips 0556 1744 1506 0037  
 0639 2015 1583 1867  
 0605 0343 0361 2214  
 Phocus 1308 0714 1652  
 Phoenix 0037 0556 0486  
 Phonola 0037 0556  
 Pilot 0556 0037 0712 0706  
 1709  
 Pioneer 1260 0760 1457 0170  
 0679 0037 0556 0343  
 0361 0109 0287 0486  
 0512  
 Pionier 0486  
 Plantron 0037 0556 0264  
 Playsonic 0714 0037 0715 1652  
 Polar 0037  
 Polaroid 1523 1667 1720 1645  
 3296 1687 2125  
 Policom 0109 0361 0074 0535  
 Portland 0624  
 Powerpoint 0487 0037 0556 0698  
 0706 1770  
 Pragma Digital 0808  
 Prandoni-Prince 0361  
 Premier 0264 0891  
 President 0860  
 Prima 0264  
 PrimeView 1606  
 Princess 0698 1326  
 Prinston 1037  
 Prinz 0361  
 Pro Vision 0499 0037 0556 1037  
 0714 1324  
 Profex 0361  
 Profilo 1556  
 Profitronic 0037 0556  
 ProLine 0634 1727 1613 1037  
 1545 0625 0037 0556  
 2223 2393 1163 1585  
 1667  
 Prosonic 0037 0556 1865 0880  
 0371 0668 0714 2139  
 2001 1324 1770 2106  
 1709 1163 0606 2197  
 2100 2125 1545 1849  
 0715 1523  
 Protech 0037 0556 0264 0668  
 0486 1037  
 Proton 0178  
 Proview 1687 1645  
 PVision 2001  
 Pye 0037 0556  
 Quadro 0753 1326 0556 0037  
 1667 1163  
 Quartek 1606  
 Quasar 0650 0865  
 Quelle 0037 1505 0109 0512  
 0535 0191 0361 0074  
 0668 0556 0195 0264  
 1037  
 Radialva 0109 0037 0556 0287  
 Radiola 0037 0556  
 Radiomarelli 0037 0556  
 Radionette 0714  
 RadioShack 0037 0556 0178  
 Radiotone 0037 0556 0668 0264  
 1037  
 Rank Arena 0753  
 RCA 0625 0093 0560 0335  
 0343 0753  
 Realistic 0178  
 Recor 0037 0556

Rectiligne 0037 0556  
 Red 2032  
 Red Star 0037 1556 0556  
 Rediffusion 0361  
 Reflex 0037 0556 1037 0668  
 Relisys 0865 1298 1585 1645  
 Reoc 0714 0624 0634 2197  
 Revox 0037 0808 0556  
 Rex 0264  
 RFT 0292 0264 0037 0556  
 0486  
 Ricoh 0037 0556  
 Rinex 0698 0264 0706  
 R-Line 0037 0556  
 Roadstar 1037 0715 0037 0556  
 0714 0668 0264 1916  
 1326  
 Rodex 0037 0556  
 Rolsen 0037 0556 2098 2037  
 2001  
 Rowa 0264 0698 0712 1441  
 0706 0587 0037 0556  
 0606  
 Royal 0606  
 Royal Lux 0335  
 Rukopir 0556 0037  
 Saba 0625 0109 0560 0343  
 0287 0361 0335 0650  
 0714 1588 1585  
 2197  
 Saga 2197  
 Sagem 0610 0830 0618  
 Saisho 0634 0264  
 Saivod 0037 1982 0556 1163  
 1556 0668 0712 1037  
 1667  
 Salora 0361 0373 0208 0480  
 1556 2125 2197 2001  
 0335  
 Salsa 0335  
 Samsung 2051 0812 0618 0587  
 1458 1619 0556 1249  
 1312 2103 2137 1630  
 0644 1235 0037 1584  
 0264 0718 0178  
 Sandström 2197  
 Sansui 0037 1682 1709 0556  
 0706 0371 0888 0753  
 0698 0264 0806 0714  
 1248 1681 1556  
 Sanyo 0208 1208 0292 0373  
 0037 0556 0486 0170  
 1037 1667 1163 1585  
 2461  
 Save 0037 0556  
 SBR 0037 0556  
 Schaub Lorenz 2241 0714 0361 2197  
 0606 0486 1324 1363  
 2100 1667 2125 1308  
 1163 1585  
 Schneider 1137 0037 0556 1585  
 0343 0371 0361 0668  
 1037 0714 0624 1982  
 1916 1617 1324  
 Schönteck 1037  
 Scott 1983 0178 1523 1795  
 Sears 0178  
 Seaway 0634  
 Seelver 0556 1037 0037  
 SEG 1037 2239 1709 0037  
 1163 0556 0668 0487  
 0264 0634 0624 1667  
 2125 1523 1585  
 SEI 1505 0037 0556  
 Sei-Sinudyne 1505 0037 0556  
 Seitech 1324  
 Selecline 3296  
 Seleco 0371 0264  
 Sencor 0714 2239 2197  
 Sense 1849

Sentra 0035  
 Serie Dorada 0178  
 Serino 0610 0093 1193  
 Sharp 1659 0093 1193 2214  
 1587 1819 0653 1163  
 Shinelco 2241  
 Shintoshi 0037 0556  
 Shivaki 0037 0556 0443 2007  
 0178  
 Show 0698 0264 0706 0037  
 Siemens 0191 0535 0195 0037  
 0556 0361  
 Siera 0037 0556 0587  
 Silva 0037 0556 0361  
 Silva Schneider 0753 1556 2125 2197  
 Silver 0037 0361 0556 0715  
 SilverCrest 1037 0037 0556  
 Singer 0806 0698 1556 0037  
 0556 0335  
 Sinotec 0606 0698  
 Sinudyne 1324 1667 0361 1505  
 0037 0556 0606  
 Sky Media 0037 0880 1614 0178  
 0556 1613 1606 1775  
 1709 0661 0865  
 Skysonic 0753  
 Sliding 0865 0880 1324  
 SLX 0668  
 Smaragd 0487  
 Soemtron 0865 1298  
 Solavox 0361 0037 0556  
 Sonic 0753 1702  
 Soniko 0037 0556  
 Soniq 1298 1702  
 Sonitron 0208  
 Sonneclair 0037 0556  
 Sonoko 0037 0556 0264  
 Sonolor 0208 1505 0361  
 Sontec 0037 0556  
 Sontech 1983  
 Sony 1825 1505 1651 1751  
 1625  
 Sound & Vision 0037 0556  
 Soundesign 0178  
 Soundwave 0037 0556 0715  
 SOVOS 2239  
 Soyo 1709  
 Standard 0037 2032 0556 1682  
 1037 1709  
 Starion 1037  
 Starlite 0037 0556 0264  
 Stern 0264  
 Stevison 1982 1556  
 Strato 0037 0556 0264  
 Strong 1163 1667 1037 0037  
 0556  
 Sungoo 1248 2037  
 Sunic Line 0037 0556  
 Sunkai 0610 0037 0556 0487  
 0865 1523  
 Sunny 0037 1617  
 Sunstar 0371 0037 0556 0264  
 Sunstech 2001 2241  
 Sunwood 0037 0556  
 Supersonic 0208 0556 0698 0264  
 0037  
 SuperTech 0037 0556  
 Supervision 0698 0264  
 Supra 0178 0037  
 Susumu 0335 0287  
 SVA 0698 0264 0208 0706  
 Svasa 0698 0208 0706 0264  
 Swedx 1606  
 Swisstec 1775 1709 1614 1606  
 1613 0880 0865 1776  
 1849 2059  
 Sysline 0037 0556

T+A 0447  
 Tandberg 0109 0361  
 Tandy 0093  
 Targa 0618  
 Tashiko 0170  
 Tatung 1720 0037 1248 1556  
 0556 1324 1916  
 Taurus 2197  
 TCL 1916 0625  
 TCM 0714 0808 2001 1308  
 Teac 0698 1645 2168 0037  
 0712 1037 0556 1795  
 0512 0668 0706 0264  
 0624 0178 0170 0714  
 1667 1617 1363 0587  
 1770 1709 2032 2241  
 1983  
 TEC 0335 0037 0556 0361  
 Tech Line 0037 1585 0556 0668  
 1163  
 Technica 1982  
 Technical 1667  
 Technics 0650  
 Technika 2106 2032 1865 2168  
 2059 1849 1667 1983  
 1585 2125 2197 1982  
 TechniSat 0037 0556 2422  
 Technisson 0714 1652  
 Techno 1585 1037  
 Technol Ace 0698 0264 0634  
 Technosonic 0625 2032 1982 0499  
 0556 1324 0880 0037  
 1326 0714  
 Technotrend 1702  
 Techvision 1709 2032  
 Techwood 1163 1037 1667  
 Tecnimagen 0556  
 Teco 1523  
 Tedalex 0698 0706 0606 0037  
 0208 0891 0587 0556  
 0806 1709 1681 0264  
 1682  
 Tek 0820 0037 0698  
 TELE System 2125 1585 1037 0037  
 2241 1667  
 Teleavia 0109 0287 0343  
 Telecor 0037 0556  
 Teledex 0037  
 Telefunken 0625 2239 1667 0560  
 0808 0587 0074 0109  
 0698 0712 0343 0820  
 0896 0754 0780 0891  
 0287 0335 1681 0753  
 0706 0037 0556 0486  
 0714 1556 1585 1588  
 1163  
 Telefusion 0037 0556  
 Telegazi 0037 0264 0556  
 Telemeister 0037 0556  
 Telesonic 0037 0556  
 Telestar 0037 0556 1849  
 Teletech 0037 0556 0668 1037  
 Television 0037 0556  
 Telstar 1702  
 Tempest 0037 0556 0264  
 Tennessee 0037 0556  
 Tensai 0037 0556 0371 0715  
 1037  
 Tesla 1037 0037 0668 0714  
 1652 0715 1137 0371  
 0753 0556 0610  
 Tevion 1248 1298 0556 1645  
 1556 1667 2032 0668  
 0808 0865 2100 1137  
 1687 1037 2241 1585  
 0714 0037 2125 2197  
 1523



Thes 1849  
 Thomson 0625 0560 0343 0287  
 0109 0335 1588 0037  
 0556  
 Thorn 0108 0109 0343 0361  
 1505 0074 0499 0535  
 0037 0556 0335 0512  
 0035  
 Thorn-Ferguson 0108 0109 0361 0499  
 0335 0035  
 Time 1702 1997  
 TMK 0178  
 Tokai 0037 0556 0668 1037  
 Tokaido 1037  
 Tokyo 0035  
 Tongtel 0780 0587  
 Top Show 0698 0264 0706  
 Topline 1037 0668  
 Toshiba 1508 0508 0035 1667  
 0714 0718 1582 0195  
 0191 0618 1916 0037  
 1556 0650 1037 1163  
 1652  
 Tosumi 1982 1770  
 Toyota 0371 0264  
 Trakton 0264  
 TRANS-continentals 0668 1037 0865 0556  
 0037 0486  
 Transonic 0037 0556 0587 0512  
 0264 0698 0712 1363  
 1326 0780 0706  
 Triad 0037 0556  
 Trio 1687 1248 1645  
 Tristar 0264  
 Triumph 0556 0037  
 TVE 2239  
 TVTEXT 95 0556  
 Uher 0037 0556 0486 0480  
 Ultravox 0037 0556 1585  
 UMC 1606 1775 1709 1614  
 1849 2059 2106 2168  
 Unic Line 0037 0556 0473  
 Uniden 1585 1037 0037 1667  
 1163  
 United 0714 1983 0037 0715  
 0556 1916 1037 0587  
 1982 2241 1652 1849  
 3296 1770 0508 1523  
 2125 1163  
 Unitek 1709  
 Unitron 1681  
 Universal 0714 0037 0556  
 Universum 0808 1037 0037 1163  
 0668 0480 0195 0473  
 1667 0535 0361 0512  
 0264 0556 0074 1505  
 0109 0170 0618  
 Univox 0037 0556  
 V7 Videoseven 0178 0880 1666 0618  
 1651 1505  
 Vanguard 0037 0556  
 Venturer 1727 1545 1865  
 Venus 1326  
 Vestel 1037 1163 1585 1667  
 0037 0668 0556  
 Vexa 0037 0556  
 Victor 0653  
 Videocon 3296  
 VideoSystem 0037 0556  
 Vidtech 0178  
 ViewSonic 1588 2111  
 Vision 0037 0264 0556  
 VisionPlus 2106  
 Vistar 0361  
 Vistron 1363  
 Visual Innovations 2106

Vivax 1326 1308 1617 1702  
 0037 1709  
 Vivo 2032 2100  
 Vortec 0037 0556  
 Voxson 0037 0556 0178 2197  
 Vue 1236  
 Walker 1667 1163 0037 1037  
 1585  
 Waltham 0287 0037 0556 0668  
 0109 1037 0443 2007  
 Watson 1037 1248 0556 0037  
 0668  
 Watt Radio 0486  
 Wega 0037 0556  
 Wegavox 0037 0556 1667  
 Welltech 0714 1652  
 Weltblick 0037 0556  
 Weltstar 1037  
 Weston 0037 0556  
 Westwood 1585  
 Wharfedale 0896 1983 1613 1667  
 1324 0891 0860 0698  
 0706 0037 1037 1681  
 0714 0556 1556  
 White  
 Westinghouse 0037 0556 0624  
 Wilson 0556  
 Windsor 0668 1037  
 Windy Sam 0556  
 Wintel 0714  
 World-of-Vision 0880 0865 1298 1606  
 XDome 0508  
 Xenius 0634 1667 1585  
 Xiron 1983 1037  
 XLogic 0698 0860 0706  
 XMS 1441  
 Xomax 1770  
 Xoro 1324  
 Xrypton 0037 0556  
 Yakumo 1613  
 Yamaha 0650 1576  
 Yamishi 0037 0556  
 Yokan 0037 0556  
 Yoko 0037 0556 0264 0373  
 YU-MA-TU 0037  
 Yüsmart 1613  
 Zenith 0624  
 Zepto 1585

# SAT

@sat 1300  
 @Sky 1334  
 ABSat 1323 0713  
 Acoustic Solutions 1284  
 ADB 0887 2553 1473 1492  
 2152 2367  
 Adcom 0200  
 AGK 2139  
 Agora 1284  
 Airis 1659 1993  
 Akai 0200  
 Akura 1626  
 Alba 2296 1284 1659 0713  
 2034  
 Allsat 0200  
 AllTech 0713  
 Allvision 1232 1334  
 Alpha 0200  
 Altech UEC 1959 2097 1960 2059  
 Amitronica 0713  
 Ampere 0396 0132

Amstrad 0132 1693 0847 0885  
1175 1662 2139 0396  
0713 0742 0501

AMTC 1993

Anglo 0713

Ankaro 0713

Ansonic 2418

Antiference 1284

Apro 1672

Arcon 0132

Arena 1736

Armstrong 0200

Arnion 1300

ASA 0299 0740

Asat 0200

ASCI 1334 0114

Asda 1284

ASLF 0713

AssCom 0853

Aston 1129

Astra 0713

Astratec 1743 1929

Astell 0885 1986 2418

Astro 0133 0173 2026 0501  
0658 1099 1100 0200

Atlanta 2418 1993

Atlantic Telephone 1333

Audiola 2418

Audioline 1429

Aurora 0879 1333 1433

Austar 1459 0879

Austriasat 1195 1197

Auvisio 2531

Avalon 0396

Avanit 0299 1631

AWA 1659

Axil 1777 1993 1659 2418

Axis 1111

Axitronic 1626

B.net 1672

B@ytronic 0299 0740

Balmet 1232

Base 1718

Belson 2418 2139 1993

Best Buy 1993 2139 2728 2418

Beyonwiz 2379

Black Diamond 1284

Blaupunkt 0173

Blizoo 2145 1736

Blue Sky 0713 0885

Boca 0132 0713 1232 2026  
2308 2458 2533

Boshmann 1413 1631

Boston 0132

Boxer 1458 1957 1692 2443

Brainwave 0658 1672

British Sky  
Broadcasting 1662 1175 0847

Broco 0713

BSkyB 1662 1175 0847

BT 1176

BT Vision 1176

Bubu Sat 0713

Bush 1284 1626 1672 2418  
1645 1743 2376 1291  
0742 1935 2034

Cablecom 1195 1197 1545

Cabovisão 1300 1631

Caiway 2443

Cambridge 0501

Canal Digitaal 0853 1499

Canal Digital 0853 1780 1004 2553  
1334

Canal Plus 2107 2657

Canal+ 0853 2107 2657 1722  
1986 1232

CanalSat 2107 2657 0853

CanalSatellite 0853 2107 2657

CDV 1993

CGV 1413 1567 2034 1232  
1986

Challenger 1956

Cherokee 1323

Chess 1334 0114 0713 2026  
1626

Chili 1718

CityCom 1176 1232 0299 1777  
0658

Clarke-Tech 1806

Clatronic 1413

Clayton 1626

Clemens Kamphus 0396

Cobra 0396 2531 2728

Colombia 0132

Columbia 0132

Com Hem 1176 1915 2357

Comag 1232 1413 2026 0132  
2101 2308 2533 2458

Comsat 1413

Comwell 1956

Connexions 0396

Conrad 0573 0501 0132

Continent 1986

Coship 1672

Crown 1284

CS 1631

Cyfra+ 1076 2593 1409 0853

Cyfrowy Polsat 0253 0853 1409

Cyrus 0200

Daeryung 0396

Daewoo 0713 1743 1111

DAK 1993

Dantax 1626

D-box 1114 0723

Delta 1176 2443

Denver 2418

DGTEC 1631 1718

Digenius 0299 0740

Digi 2026 1195 1197 1300

Digi Raum  
Electronics 1176

Digitality 1334

DigiFusion 1645 1743 1929

Digihome 1284 2034 1935

Digiline 2273

DigiLogic 2034 2241 1993

DigiMax 2273

DigiQuest 1473 1300 1631

DigiSat 1232

Digital 2308 2273

Digital Vision 1929

Digital+ 0853

DigitAlb 1232

DigitalBox 1631 2540 1100 1886

Digitel+ 1659

Digittrade 1659

DigiTurk 2097 1076

Dikom 2531

Dilog 1780 1957

DiPro 1473

Distratel 0885

Distrisat 0200

Diunamai 2531

DNA 2357 1780 1957 1176  
2144 1545 1323

DNT 0200 0396

Doro 1672

DRE 1176

Dream  
Multimedia 1237 1923 1652

DSE 2280 2418

DStv 0879 2059 2060 1959  
1960 1333 1433

Dual 2034

Durabrand 1284 2241 2034  
 DVX 1993  
 Echostar 1200 0853 0396 0713  
 1323 1473 1409  
 Eco-Star 1413  
 Edision 1631 2306 2712  
 Einhell 0132 0713 0501  
 Elap 0713 1409 1611 1129  
 1567 1413  
 Elbe 2418  
 Electron 1956  
 Elless 0740  
 Elsat 0713  
 Elta 0200 1659  
 Emtec 1659  
 Energy Sistem 1631 2418  
 Engel 1777 0713 1672 1993  
 Etisalat 2443  
 Eurieult 0885  
 Europa 0501 0200  
 Europhon 0299 0132 0713 1334  
 Europsat 1413 1611  
 Eurosat 1567 1886  
 Eurosky 0132 0299 0114 0501  
 0740  
 Euro-Vox 0744  
 Eutelsat 0713  
 Eutra 0740 0299  
 Evesham 2034  
 Evolve 1993  
 F&U 2139  
 Fagor 1611  
 FaVal 1631  
 Fenner 0713  
 Ferguson 1291 1743 1929 1935  
 2034 1284  
 Fidelity 0501  
 Finepass 1780  
 Finlux 1626 2034 0573 1232  
 1284  
 FinnSat 0740  
 Flair Mate 0713  
 FMD 1413 0114  
 FoneStar 1777  
 Foxtel 1356 1459 0879 1176  
 FPE 1993  
 Free Wave  
 Technology 1743  
 Freecom 0501 0173  
 Freesat 2376 1692  
 Freesat+ 2443  
 Fte Maximal 0713 1886  
 Fuba 0396 0173 0573 0299  
 Fuji Onkyo 1631 2728 2101  
 Galaxis 1111 1176 0853 0879  
 Galaxy 1956  
 General Satellite 1176  
 Geser 1631  
 Get 1004  
 Globalteq 2145  
 Globo 2273 1626 1429 1334  
 2026 0740  
 Go 1780  
 GOD Digital 0200  
 Gold Box 0853  
 Gold Vision 1631  
 GoldMaster 1334 1722  
 Goodmans 1284 2034 1291 2376  
 1743 2296  
 Gradiente 0887  
 Gran Prix 0740  
 Grandin 1626  
 Grocos 1409  
 Grundig 0173 0847 2367 1291  
 1284 2376 1672 0879  
 0885 0853 0501 1780  
 2034

Haier 2418  
 Hallo 1626  
 Hama 1567  
 Handan 1780 1957  
 Hanseatic 1099 1100  
 Hänsel & Gretel 0132  
 Hauppauge 1672  
 HB 1736  
 HE@D 2183  
 Hills 1232  
 Hirschmann 0396 1886 1111 2026  
 0173 0573 2308 0299  
 1232 0501 0740  
 Hitachi 2034 1284  
 HNE 0742 1232 0132  
 Homecast 1680 1736  
 Houston 0396  
 Humax 0215 1176 1232 1808  
 1427 1915 2144 1882  
 1788 1675 1743 2357  
 2443  
 Huth 0132  
 Hyundai 2034  
 i-Box 1652  
 i-CAN 2367  
 Icecrypt 1631  
 ID Digital 1176  
 ID Sat 2145 1334 1631  
 Illusion Sat 1631  
 Image 1993  
 Imagin 1195 1197  
 Imperial 1429 1334 1099 1100  
 1197 1195 1351 0200  
 1672 1631  
 iNETBOX 1652  
 Ingelen 0396  
 Inno Hit 1626 2728  
 Intek 2204  
 International 0132  
 Interstar 2200  
 Inves 1993 1743  
 inVion 2418  
 iotronic 1413 0132  
 i-SET 1567  
 Isis 1284 2034  
 ITI Neovision 2152  
 ITT 2418  
 ITT Nokia 0573 0723  
 Jaeger 1334  
 Jepssen 2204  
 JVC 1284  
 Kabel Deutschland 1195 1197 1882 2443  
 1915 1672  
 KabelBW 1882 1915 1195 1197  
 2176 1176 1429  
 KabelNoord 2443  
 Kamm 0713  
 Kaon 1004 1300  
 KaTelco 1111  
 Kathrein 2569 1561 0707 1567  
 0658 0249 1717 0114  
 0173 0200 0713 0742  
 1323  
 Kendo 1284  
 Kenwood 0853  
 Key West 0132  
 Kiton 0114  
 Kocmoc TB 1333  
 Kongque 1300  
 König 1631 1567  
 Koscom 1956  
 KPN 1986 1545  
 Kreiling 0658 0249 0114 1626  
 Kreiselmeyer 0173  
 Krystel 1284  
 K-SAT 0713  
 Kyostar 0132

L&S Electronic 0132 1334  
 Labgear 0744  
 LaSAT 0132 0299 0740 0173  
 Lauson 2531  
 Legend 1718  
 Legend Digital 1718  
 Leiker 2728  
 Leiko 1626  
 Lemon 1334  
 Lenco 0713  
 Lennox 1611  
 Lenson 0501  
 Lexus 0200  
 LG 1414  
 Lifesat 0132 0299 0713  
 Linsar 1284  
 Listo 1626  
 Liwest 1195 1197  
 Lodos 1284  
 Logik 1284 2441 2034  
 LogiSat 2026 2458  
 Lorenzen 0299 0742 2026 0132  
 Lowry 1284  
 Luxor 1935 2034 0573 0501  
 M vision 2273  
 Macab 0853  
 Manata 0713 0132  
 Manhattan 1300  
 Maplin 2034  
 Marantz 0200  
 Marks & Spencer 2441  
 Mascom 1680  
 Maspro 0713 0173  
 Matsui 1626 0173 1743 1929  
 1284 0200  
 Maximum 1334 2552 1986  
 Mediabox 0853  
 Mediacom 1206  
 MediaSat 0501 0853 2107  
 Mediaset 2367 1427 1473  
 Medion 1232 0299 0713 0132  
 1626 1334 0740 2026  
 Medison 0713  
 Mega 0200  
 Megasat 1631 1886 0740 0299  
 2034 1284  
 Metronic 1284 1659 1935 0713  
 1631 2418 0132 0885  
 1993 1986 1413 1672  
 Metz 0173  
 MiCO 1993  
 Micro 2308 0501 0713  
 Micro electronic 0713 2308 2458  
 Micro Technology 0713  
 Micromaxx 0299  
 Microstar 0299  
 Microtec 0713  
 Morgan's 0132 0713 0200 1232  
 1409  
 Motorola 0856 1473  
 Multichoice 2059 0879 1959 1960  
 2060 1333 1433  
 Murphy 2034  
 Mx Onda 1659  
 Myryad 0200  
 Mysat 0713  
 MySky Italia 1693  
 MySky  
 New Zealand 1356  
 N 2152  
 NanoXX 2204 1631  
 NC+ 2593  
 Nekkassat 0744  
 Neom 1993  
 Neosat 2273  
 Neotion 1334  
 Netgem 1322

Neuf TV 1322  
 Neuhaus 0501 0713  
 Neuling 1232 0132 2458 2026  
 Neusat 0713  
 Nevir 1659 2728  
 New Line 1993  
 Newton 0396  
 NexPRO 1631  
 Next 2200  
 NextWave 1956  
 Nikko 0713 0723 0200  
 Noda Electronic 0885  
 Nokia 1114 1023 0723 0853  
 0573  
 Noos 0853  
 Nordmende 1611  
 Nova 0879 1959 1960 2059  
 2060 1333  
 NPG 1631 2531  
 NTV Plus 1692  
 Numericable 0853 0099  
 OctalTV 1429  
 OKI 1567  
 Omni 1993  
 Onn 1284 2034  
 Openbox 1662 1956  
 Opensat 1956  
 Opentech 2525  
 Opentel 1232 2525  
 Optex 1777 1232 1993 0114  
 0713 1611 1626 1413  
 Opticum 2273  
 Optus 1356 0879 0853  
 Orbis 1334 1232  
 Orbit 0215  
 Orbit Showtime  
 Network 1959 1960 0879  
 Orbitech 1195 1099 1100 1197  
 0200 0501 0114 1351  
 Orion Express 1986  
 Orton 2273  
 P&T Luxembourg 1322  
 P/Sat 1232  
 Pace 1175 1693 1717 2097  
 2593 2657 1356 0847  
 2059 1662 2060 1323  
 0887 1682 0200 0853  
 Pacific 1284  
 Packard Bell 1111  
 Palcom 0299 1611 1409  
 Palladium 0501 0396  
 Palsat 0501  
 Panasat 0879 1959 1960 1333  
 Panasonic 0847 1304  
 Panda 0173  
 Patriot 0132  
 peeKTON 1993 2418  
 Philips 0099 2097 2107 2176  
 2593 1076 1114 1499  
 0853 0133 0200 1672  
 1743 0173 1429  
 Phoenix 2418 1956  
 Phonotrend 1200  
 Pino 1334  
 Pioneer 0853  
 Planet 0396  
 PMB 1611 0713  
 Polytron 0396  
 Power Sat 1886  
 Preisner 0132 0396  
 Premiere 1114 1915 0723 1176  
 1195 1100 1882 1675  
 1788 0249 1111 0658  
 1717 2176 1499 1197  
 Premium 1736  
 Primacom 1111  
 Pro Basic 0853 2531

ProLine 1284 1659  
 Prosonic 0742  
 Quadral 1323  
 Quelle 0742 0299  
 Radiola 0200  
 Radix 0396  
 RCA 1291  
 RFT 0200  
 RiksTV 2367 1692  
 RIO Media 1780  
 Roadstar 0713 0853  
 Rollmaster 1413  
 Ross 2540  
 Rover 0713  
 Rownsonic 1567  
 SAB 1956 1300 1631  
 Saba 2205 0885  
 Sagem 2107 2553 1114 1690  
 1692 1004  
 Sagemcom 1692  
 Saivod 2418  
 Salora 1232  
 Samsung 2176 1662 1693 1458  
 1206 0853 1682 0253  
 1175  
 Sansui 1545  
 Sanyo 1626  
 Sappa 2204  
 SAT 0501  
 Sat Control 1300  
 Sat Industrie 1611  
 Sat Partner 0501  
 Sat Team 0713  
 SAT+ 1409  
 SatCatcher 1956  
 Satec 0713  
 Satlink 2273 1567  
 Satplus 1100  
 SatyCon 1631  
 Schaub Lorenz 2034 2418  
 Schneider 1206  
 Schwaiger 2533 1334 1631 2458  
 0740 0885 1111 1429  
 1672 2308 0132  
 SCS 0299  
 Sedea  
 Electronique 0132 1626 0114  
 Seeltech 1993  
 Seemann 0396  
 SEG 2235 1626 0742 0114  
 1993 1659 1284 2034  
 Septimo 0885  
 Servimat 1611  
 ServiSat 0713  
 Set-One 2728  
 SFR 1322  
 Shark 1631  
 Sharp 2034 1935  
 Sherwood 1611 1409  
 Siemens 0173 1626 1657 1334  
 1429 2418 1672  
 Sigmatek 2139 2418  
 SignalMAX 1956  
 Silva 0299  
 Silva Schneider 0740  
 SilverCrest 2026 2101 2308 2458  
 Simz 2241  
 Skantin 0713  
 SKR 0713  
 SKT 0132  
 Sky Deutschland 1114 1915 0723 1197  
 1176 1195 1100 1882  
 1675 1788 1499 1111  
 0249 0658 1717 2176  
 0099 1351 2443 2357  
 Sky Italia 1693  
 Sky New Zealand 0856 0887 1356

Sky UK 1662 1175 0847  
 Sky+ UK 1175 1662  
 Skylink 1986 1722 2443 1631  
 2034 1545 1195 1197  
 1680 1957  
 Skymaster 1409 1611 0713 1200  
 1334 1567 2205 1545  
 2409 2728 2241  
 Skymax 0200 1413  
 Skypex 0299 0740  
 skyplus 2026 1232 1334 1175  
 0740  
 SkySat 0713 0501 0114  
 Skyworth 1631  
 SL 2026 0132 0742 0740  
 1672  
 SM Electronic 0713 1200  
 Smart 0132 1631 0299 0396  
 1232 0713 1413 2285  
 0740  
 Sogo 2139  
 Sonera 1780 1957  
 Soniq 1567  
 Sony 0847 1558 0639 0853  
 SR 0132  
 Star Sat 0132  
 Star View 2145  
 Starcom 0114  
 Starland 0713  
 Stream System 1300  
 Strong 1409 0713 2235 1626  
 2418 0853 1284 1300  
 0879 1473 0744 1993  
 2034 1806  
 STV 1986 2145 1736 1176  
 Sunny 1300  
 Sunsat 0713  
 Sunstar 0132  
 Sunstech 1993 2139 2418  
 Supratech 1413 2139  
 Systec 0132 1334  
 Sytech 2139 2418  
 S-ZWO 1722  
 TBoston 2418 1659 2139  
 TBS 1284  
 Teac 1322 1957  
 Tecatel 1200  
 Technika 2034 2441 1284 1672  
 1626  
 TechniSat 1195 1197 2540 1100  
 1099 0501 1351 1322  
 0200 0114 0396  
 Technosat 1206  
 Technosonic 1672  
 Technotrend 1429 1672  
 Technowelt 0885 0132  
 Techwood 0114 1284 1626 2034  
 1935  
 TELE System 1611 1409 0396 1993  
 Tele2 1195 1197  
 Telecom 0713  
 Teleka 0396 0501  
 Telearstar 0501 1099 1100 0114  
 0200 1429 1334 1351  
 1626 1672 1195 1197  
 2540  
 Teletech 0114  
 Televs 0501 2101 0132 1300  
 1334 1409  
 Telewire 1232  
 TelSKY 2540  
 Telstra 1356  
 Tesla 1626  
 Tevion 1672 1334 0713 1409  
 1567 2205  
 T-Home 1692 1004

Thomson 0847 1291 2107 2176  
 1175 0853 1662 1459  
 1935 0713

Tiny 1672

Tioko 0132

Titan 1886 2205

Tividi 1429 1736

T-Mobile 1545 2443

TNT Pass 1567

TNT SAT 2235 1692 1986 1195  
 1197

Tokai 0200

Tonna 1777 1611 2458 0501  
 0713

Top Up TV 1935

Topfield 1986 1545 1783 1722  
 1206 1824

Toshiba 1284

Triasat 0501

Triax 0501 1722 1986 0200  
 0396 0713 0853 0114  
 1291 0132 1099 1626  
 1611 1413 2101 1886

Tricolor TV 1176 1915

TT-micro 1429

Turnsat 0713

TV Vlaanderen 0853

TVonics 2441

Twinner 0132 0713 1611

UEC 0879 1356

UfaNet 1986

Umax 1993

Unisat 0200 0132

United 2418 1626

Unitymedia 1429 1882 1176 1195  
 1197 1915 2443

Univers 1886

Universum 0173 0299 0742 0114  
 1099 0740

UPC 1176 1076

UPC Direct 2443

Van Hunen 0299

Vantage 2297 1458 2204

Vaova 1993

Variosat 0173

VEA 2418

Vectra 1195 1197

Ventana 0200

Vestel 0742 1284 0114 1626

VH Sat 0299

Viasat 0253 1323 1682 1023  
 1195 2235 1197

Viola Digital 1672

Virgin Media 2441

Vision 1626 1886

VisionNet 1631

Visiosat 1718 1413 1631 0713  
 0114 1129

Vistron 0740 0299

Vitecom 1413 2531

Volcasat 2418

Volia 1957 1780

Voo 0853

Walker 2034

Wavelength 1232 1413

Welho 2357

Wetekom 0501

Wharfedale 1284 2034 0200 1935

Wisi 0173 0396 0299 0501  
 0132 0740 1232 1986

Worldsat 1473 0114

Woxter 2418 2139

Xsat 0713 1323

Xtreme 1300

Yakumo 1413

Yamada 1718 1993 2139

YES 0887

Youview 1176

Yukai 1659

ZapMaster 0740

Zehnder 1777 1334 1232 1413  
 0114 0742 1631 2388  
 0744 2235 1886 2034  
 0740

Zenith 0856

Zeta Technology 0200

Ziggo 1657 1499 2443

Zinwell 1176 2280

Zircon 1631

Zodiac 2531

# CBL

@Home 1666 2015 0660

ADB 2343

Akado 2339 2043

Altibox 2030

Amino 1615

Belgacom TV 2132

BT Vision 2294

Cablecom 1582

Caiway 2015 0660 1666

Canal Digital 2030

Cisco 2506 2589 2132 1582

ClubInternet 2132

Com Hem 0660 1666 2015

Comcor 2339

Cyfrowy Polsat 1666

Delta 0660 2015 1666

Deutsche Telekom 2132

Digi 0660

DNA 1666 0660 2030

Elion 1615

freebox 1976 1482

Gala 2030

Glashart Media 1615

GuestComm 2030

Humax 0660 1813 2043 2339  
 1885 1983 2165 1981  
 2620

Jambox 2030

Kabel Deutschland 1981 1983 2165 1666  
 2174 2620

KabelBW 1813 2174 1981 1983  
 1060

KabelNoord 2015

Kiss 2132

Kreatel 2030

Lattelecom 2030

Magio Sat 2132

Magnet 1615

Motorola 2030

MTS 1615

NTL 1060 1068

Ono 1068

Optus 1060

Orange 2407

Pace 1068 2620 1060 2294

Philips 1619 2174 2294 1582

Premiere 2620 2174 1813

PrimeTel 2030

PrimeTV 2030

Qwerty 1615

RIO Media 2030

Sagem 2407

Sagemcom 2407 0660

Samsung 2407 2015 2174 1060  
 1666 1987 2610 2368  
 2589

Scientific Atlanta 2132

Sky Deutschland	2620 1813 2174 1619 1885 0660
Sonera	1666 0660
Starman	0660
Stofa	2015
STV	0660
T-Com	2132
TDC	2368
Tele2	0660
Telewest	1068 1060 1987
Telia	2030
Telset	0660
TelstraClear	2343
Teo	2030
T-Home	2132
Thomson	1582 1981 2174 2407 1983
TP	2407
Unitymedia	2610 1813
UPC	0660 1582
UPC Cablecom	1582
Vector	2030
Viasat	2030
Viken Fibernett	2030
Virgin Media	1060 1068 1987
Vodafone	1615
YouSee	2368
Ziggo	2015 2589 0660 1666

Pinnacle Systems	1447
PopBox	2260
Popcorn Hour	2260
RaidSonic	2238
Ricavision	1272
Sitecom	1843
Sony	1733
SoundGraph	2037
Sumvision	2628
Thermaltake	2037
Trust	1272
TViX	2153
Via Technologies	1272
Western Digital	2558
Woxter	2628 2535 2709
XBox	1272

# VIDAC

A.C.Ryan	2709 2535
Antec	2037
Apple	2615
Argosy	2270
ASRock	1272
Asus	1272
ATMT	2270
Bang & Olufsen	0875
Best Buy	2522
Captiva	2270
chiliGREEN	2535 2628
CnM	2535
Dane-Elec	2628
Digitech	2260
DVICO	1921 2153
EGreat	2260
Elonex	1272
Eminent	2260
Emtec	2535 2709
EverTech	2535
Fantec	2535 2522 2709
Freecom	1843
Fujitsu Siemens	1272
Galaxy	2238
Hauppauge	1408
Hewlett Packard	1272
hFX	1272
iconBIT	2709
ICY Box	2709
iMON	2037
INOi	2270
Iomega	2270 2238
ISTAR	2260
LaCie	2238 2626
me2	2535 2270
Memup	2270 2522
Microsoft	1272
Muvid	2522
Netgear	2036
Nilox	2522
Olidata	2270
Packard Bell	2238
peeKTON	2116

**English**

UNIVERSAL ELECTRONICS INC./ONE FOR ALL warrants to the original purchaser that this product will be free from defects in materials and workmanship under normal and correct use for a period of one (1) year from the date of original purchase. This product will be replaced free of charge if it has been proven to be defective within the one (1) year warranty period. This warranty does not cover cartons, carrying cases, batteries, broken or marred cabinets or any other item used in connection with the product. Any further obligation than listed above is excluded. To obtain warranty service during the warranty period, please call us at the number mentioned on the Customer Service page. Please notice that we need your purchase receipt so that we may establish your eligibility for service. If you have bought this product for purposes which are not related to your trade, business or profession, please remind that you may have legal rights under your national legislation governing the sale of consumer goods. This guarantee does not affect those rights.

**Universal Electronics BV  
Europe & International  
P.O. Box 3332  
7500 DH, Enschede  
The Netherlands**

**URC-1669  
710441**



**RDN-1080515**