
Remote Control User Manual

The compact and elegant remote control is easy to carry. It is designed to fit on a key chain, a purse, a pocket or to be hidden in the car sun visor. This remote control act as multi-purpose key for arming, disarming, arming stay, and emergency call.



Specifications:

Power Supply: DC 6V(2pc CR2032 button cell battery) Transmitting: ≤ 6mA Transmitting Distance: ≤80m (in open area) Transmitting Frequency: 315MHz/433MHz (±75KHz) Housing Material: ABS plastic Working Temperature: -10°C-55°C Humidity: Up to 80% (non-condensing) Dimension(L/W/H): 35x70x12 mm

Button Manual



🔒 Arm

Press the arm button to arm the system before leaving your home, arming LED (left) flashes once. anv detectors (in Normal Zone)



triggered will activate the system to alarm immediately. The system simultaneously calls the preset phone numbers.

Disarm **P**

Press the disarm button before entering your home. disarming LED (right) flashes once. Then you are able to move freely in your home without


 \land

arming LED (left) flashes once, the

siren beeps once.

system is in stay

arm mode. The



Stay Arm (Home Mode)



Mute Mode

Press stay arm button, then press arm or disarm button within 3 seconds to enter into arming or disarming state in mode without disturbina mute someone



Emergency Call

Once there's an emergency situation, no matter what state the alarm system is in, press SOS button once for help, both LED flashes



once, the system immediately goes into an alarm condition and notify your family.



mode are disarmed, this allows the user to move freely at home, while the rest of the system is fully armed, the accessories in normal zones will activate an immediate alarm when triggered.