



Power & Lighting

Batteries Rechargeable Packs

Video Camcorder Chargers

CAMCORDER CHARGER - UNIVERSAL

Compatible with most Camcorder Batteries including many brands and models using modern Li-Ion or early NiMH and NiCd. 3.6V To 7.2V Rapid Charge to any capacity in a very fast 2 to 6 Hours! Powered with either the supplied 240Vac power pack or 12Vdc car adaptor for a versatile take-anywhere solution. Fully automatic, Plug and charge. Easy! Intelligent Microprocessor controlled with LCD function and status display. Includes adaptors so as to suit a majority of camera batteries. Also charges AA/AAA, NiCd/NiMH cells. Charge time is dependant on the capacity of the battery.

Code
CX1500



World Voltage Adaptor featuring Australia/NZ plug which snaps off to reveal flat pins suitable for use in many countries.



CAMCORDER CHARGER - ADAPTOR SYSTEM

LITHIUM-ION CHARGER - REQUIRES AVP ADAPTOR

Suits the newer type cells as used in digital video, etc. Not suitable for Ni-Cd or Ni-MH Lithium-Ion batteries only.

This innovative system includes purchasing the DCC1 desk charger and then the ADDITIONAL adaptor to suit your particular battery. Thus the system is now dedicated to that specific camera charging.

PROCEDURE:

Purchase the DCC1 battery charger and also the AVP adaptor required: 1/ Find your cameras battery here on these pages and take note of the corresponding AVP code listed. 2/ or see the AVP Alpha listing. 3/ or give us a call !

DCC1 +AVP [AVP Depends on battery]
Order DCC1 plus an adaptor AVP-[xxx]

Code
DCC1

**REQUIRES ADAPTORS
SEE AVPxxx
See Cross-reference
listing on the next
column for an Adaptor to
suit your camera...**



**BATTERY
ADAPTORS
SOLD SEPARATELY**

DDC1 Charger Cross Reference

DDC1 VIDEO CHARGER & ADAPTOR SYSTEM

CHARGER ONLY

[Requires adaptor plate below]

Includes 240Vac Power Pack and 12Vdc car lead.

Description	Code
Charger Base Only (requires adaptor plate)	DCC1



ADAPTOR PLATES [Requires DCC1 charger]

Choose the adaptor plate to suit your battery below:

Description

Charger Base Only (requires adaptor plate)

Adaptor Plate to suit models listed below:

each



DCC1 Charger Adaptor to Suit	Code
------------------------------	------

Benq- Adaptor Only To Suit DCC1

02491-0015-00	AVP249
02491-0017-00	AVP60
DLI-102	AVP41



Canon- Adaptor Only To Suit DCC1

BP2L12, BP2L13, BP2L14, BP2L24H, BP2L5, NB-2L, NB-2LH	AVP234
LP-E5	AVP315
NB-4L, NB-8L	AVP46
NB-5H	AVP5
NB-5L	AVP56
NB-6L	AVP362
NB-7L	AVP371
BP-208, BP-308, BP-315	AVP508
BP-911, BP-914, BP-915, BP-924, BP-927, BP-930, BP-941, BP-945, BP-950G, BP-970G	AVP914
BP-508, BP-511, BP-511A, BP-512, BP-514, BP-522, BP-535	AVP511
LP-E8	AVP813
LP-E6	AVP836
NB-10L	AVP802
LP-E10	AVP801



Casio- Adaptor Only To Suit DCC1

NP-30, NP-30DBA	AVP60
NP-50	AVP375
NP-60	AVP79
NP-80	AVP140
NP-20	AVP20
NP-130	AVP233



Fujifilm- Adaptor Only To Suit DCC1

NP-60	AVP60
NP-40	AVP41
NP-45	AVP140
NP-50	AVP368
NP-70	AVP128
NP-95	AVP95
NP-140	AVP142
NP-150	AVP135
NP-120	AVP61
NP-W126	AVP832

**AVP Adaptor
REQUIRES DCC1
SOLD SEPARATELY**

Hitachi- Adaptor Only To Suit DCC1

02491-0028-01	AVP830
DZ-BP14, DZ-BP21, DZ-BP7	AVP407
VM-BPL13, VM-BPL27, VM-BPL27A, VM-BPL30, VM-BPL60	AVP550
DZ-BP14, DZ-BP14R, DZ-BP16, DZ-BP28	AVP120

JVC- Adaptor Only To Suit DCC1

BN-V607, BN-V615, BN-V812, BN-V814	AVP550
BN-V107, BN-V114	AVP107
BN-VM200	AVP208
BN-V37U	AVP37
BN-VF707, BN-VF714, BN-VF733	AVP707
BN-VF808, BN-VF815, BN-VF823	AVP808





DCC1 Charger Adaptor to Suit

Code

Kodak- Adaptor Only To Suit DCC1

KLIC-5000	AVP60
KLIC-7006	AVP140
KLIC-7004	AVP368
KLIC-7000	AVP189
KLIC-7001	AVP771
KLIC-7002	AVP772
KLIC-7003	AVP773
KLIC-8000	AVP850
KLIC-5001	AVP61



Konica- Adaptor Only To Suit DCC1

DR-LB1	AVP51
--------	-------

Konica Minolta- Adaptor Only To Suit DCC1

NP-900	AVP249
NP-1	AVP41
NP-700	AVP700

Kyocera- Adaptor Only To Suit DCC1

BP-1000S, BP-800S, BP-900S	AVP51
BP-1100S	AVP411

Nikon- Adaptor Only To Suit DCC1

EN-EL10	AVP140
EN-EL3, EN-EL3e	AVP135
EN-EL8	AVP189
EN-EL7	AVP177
EN-EL9	AVP196
EN-EL11	AVP317
EN-EL12	AVP612
EN-EL19	AVP529
EN-EL14	AVP489

Olympus- Adaptor Only To Suit DCC1

Li-80B	AVP249
Li-20B	AVP60
Li-40B, Li-42B	AVP140
Li-60B	AVP317
BLL-1	AVP102
BLS-1	AVP106
Li-30B	AVP130
Li-50B	AVP152
Li-10B	AVP110
Li-70B	AVP133



AVP Adaptor
REQUIRES DCC1
SOLD SEPARATELY

Panasonic- Adaptor Only To Suit DCC1*

CGA-S301, CGA-S302A, CGA-S302E, VW-VBA10, VW-VBA20, VW-VBA21	AVP60
CGA-S005, CGA-S005E, DMW-BCC12	AVP128
CGA-DU07, CGA-DU12, CGA-DU14, CGA-DU21, VW-VBD070, VW-VBD140, VW-VBD210, VW-VBG070A, VW-VBG130, VW-VBG260	AVP407
CGR-B202A, PV-DBP5, VW-B202, VW-VBD1	AVP550
CGA-S007, DMW-BCD10	AVP171
CGA-S008, DMW-BCE10, VW-VBJ10	AVP168
CGA-S303, VM-VBE10	AVP303
VW-VBG6	AVP326
CGA-D54S, CGA-D54SE, CGP-D28A, CGP-D28S, CGP-D28SE, CGP-D320, CGP-D54S, CGR-D08, CGR-D08A, CGR-D08R, CGR-D08S, CGR-D08SE, CGR-D120, CGR-D120E, CGR-D120T, CGR-D14, CGR-D16A, CGR-D16S, CGR-D16SE, CGR-D210, CGR-D220, CGR-D220A, CGR-D220E, CGR-D28A, CGR-D320, CGR-D320A, CGR-D320E, CGR-D53A, CGR-S602, CGR-S602A, CGR-S602E, CGR-S602SE, DMW-BL14, VW-VBD21, VW-VBD22, VW-VBD25, VW-VBD33, VW-VBD35, VW-VBD40, VW-VBD55	AVP154
DMW-BCG10	AVP158
DMW-BCF10	AVP77
CGA-S002, CGA-S002A, CGA-S002E, CGA-S006, CGA-S006E, CGR-S002, CGR-S002E, CGR-S006, CGR-S006E, DMW-BM7, DMW-BMA7	AVP328
VW-VBK180, VW-VBK180GK, VW-VBK180-K, VW-VBK360, VW-VBK360GK, VW-VBK360-K, VW-VBL090, VW-VBL090GK, VW-VBL090PPK, VW-VBL360	AVP134
DMW-BCH7	AVP139
DMW-BLB13, DMW-BLB13E	AVP190
DMW-BMB9, DMW-BMB9E, DMW-BMB9GK	AVP197
DMW-BLE9, DMW-BLE9E	AVP380
VW-VBN130, VW-VBN130GK, VW-VBN260, VW-VBN260GK, VW-VBN390, VW-VBN390GK	



DCC1 Charger Adaptor to Suit

Code

Pentax- Adaptor Only To Suit DCC1

D-Li2	AVP60
D-Li8, D-Li85, D-Li95	AVP41
D-Li63	AVP140
D-Li68	AVP368
D-Li72	AVP700
D-Li78	AVP317
D-Li92	AVP152
D-Li88	AVP178
D-Li90	AVP372
D-Li7	AVP61



Ricoh- Adaptor Only To Suit DCC1

DB-40	AVP60
DB-60, DB-65	AVP128
DB-50	AVP850
DB-80	AVP317
DB-70	AVP168
BJ-8	AVP318
DB-43	AVP61



Samsung- Adaptor Only To Suit DCC1

SLB-1037, SLB-1137	AVP60
SLB-0737, SLB-0837	AVP41
IA-BH125C	AVP128
SLB-0637	AVP700
SB-L110, SB-L110A, SB-L160, SB-L220, SB-L320, SB-L480, SB-L70, SB-L70A, SB-L70R, SB-LS110, SB-LS220, SB-LS70, SB-LS70AB	AVP16
SLB-10A	AVP313
SLB-1137D	AVP391
SLB-0837B	AVP413
SLB-1137C	AVP793
SB-LSM160, SB-LSM320, SB-LSM330, SB-LSM80	AVP800
SLB-1974	AVP815
IA-BP85ST	AVP855
SBL-110G, SBL-70G	AVP870
SB-LH82	AVP882
SB-90ASL, SB-P90A, SB-P90AB, SB-P90ASL	AVP900
SLB-0937	AVP937
IA-BP85SW	AVP185
BP70A	AVP289
IA-BP80W	AVP318
SLB-11A	AVP340
IA-BH130LB	AVP341
SLB-07A	AVP357
BP85A	AVP287

AVP Adaptor
REQUIRES DCC1
SOLD SEPARATELY

Sanyo- Adaptor Only To Suit DCC1

NP-40	AVP41
DB-L30	AVP700
DB-L70	AVP317
DB-L40	AVP410
DB-L10	AVP110
DB-L80	AVP178
DBL-50	AVP61



Sharp- Adaptor Only To Suit DCC1

BT-L226, BT-L227	AVP226
------------------	--------

Sony- Adaptor Only To Suit DCC1

NPF330, NPF530, NPF550, NPF570, NPF730, NPF750, NPF770, NPF930, NPF950, NPF960, NPF970, NPFM30, NPFM50, NPFM500H, NPFM51, NPFM55H, NPFM70, NPFM71, NPFM90, NPQM91, NPQM50, NPQM51, NPQM70, NPQM71, NPQM90, NPQM91	AVP550
NP-BK1	AVP152
NP-BG1, NP-FG1	AVP181
NPFH100, NPFH30, NPFH40, NPFH50, NPFH60, NPFH70, NPFH75, NPFH90, NPFH100, NPFH100G, NPFH100H, NPFH100L, NPFH100M, NPFH100N, NPFH100P, NPFH100Q, NPFH100R, NPFH100S, NPFH100T, NPFH100U, NPFH100V, NPFH100W, NPFH100X, NPFH100Y, NPFH100Z, NPFH100AA, NPFH100AB, NPFH100AC, NPFH100AD, NPFH100AE, NPFH100AF, NPFH100AG, NPFH100AH, NPFH100AI, NPFH100AJ, NPFH100AK, NPFH100AL, NPFH100AM, NPFH100AN, NPFH100AO, NPFH100AP, NPFH100AQ, NPFH100AR, NPFH100AS, NPFH100AT, NPFH100AU, NPFH100AV, NPFH100AW, NPFH100AX, NPFH100AY, NPFH100AZ, NPFH100BA, NPFH100BB, NPFH100BC, NPFH100BD, NPFH100BE, NPFH100BF, NPFH100BG, NPFH100BH, NPFH100BI, NPFH100BJ, NPFH100BK, NPFH100BL, NPFH100BM, NPFH100BN, NPFH100BO, NPFH100BP, NPFH100BQ, NPFH100BR, NPFH100BS, NPFH100BT, NPFH100BU, NPFH100BV, NPFH100BW, NPFH100BX, NPFH100BY, NPFH100BZ, NPFH100CA, NPFH100CB, NPFH100CC, NPFH100CD, NPFH100CE, NPFH100CF, NPFH100CG, NPFH100CH, NPFH100CI, NPFH100CJ, NPFH100CK, NPFH100CL, NPFH100CM, NPFH100CN, NPFH100CO, NPFH100CP, NPFH100CQ, NPFH100CR, NPFH100CS, NPFH100CT, NPFH100CU, NPFH100CV, NPFH100CW, NPFH100CX, NPFH100CY, NPFH100CZ, NPFH100DA, NPFH100DB, NPFH100DC, NPFH100DD, NPFH100DE, NPFH100DF, NPFH100DG, NPFH100DH, NPFH100DI, NPFH100DJ, NPFH100DK, NPFH100DL, NPFH100DM, NPFH100DN, NPFH100DO, NPFH100DP, NPFH100DQ, NPFH100DR, NPFH100DS, NPFH100DT, NPFH100DU, NPFH100DV, NPFH100DW, NPFH100DX, NPFH100DY, NPFH100DZ, NPFH100EA, NPFH100EB, NPFH100EC, NPFH100ED, NPFH100EE, NPFH100EF, NPFH100EG, NPFH100EH, NPFH100EI, NPFH100EJ, NPFH100EK, NPFH100EL, NPFH100EM, NPFH100EN, NPFH100EO, NPFH100EP, NPFH100EQ, NPFH100ER, NPFH100ES, NPFH100ET, NPFH100EU, NPFH100EV, NPFH100EW, NPFH100EX, NPFH100EY, NPFH100EZ, NPFH100FA, NPFH100FB, NPFH100FC, NPFH100FD, NPFH100FE, NPFH100FF, NPFH100FG, NPFH100FH, NPFH100FI, NPFH100FJ, NPFH100FK, NPFH100FL, NPFH100FM, NPFH100FN, NPFH100FO, NPFH100FP, NPFH100FQ, NPFH100FR, NPFH100FS, NPFH100FT, NPFH100FU, NPFH100FV, NPFH100FW, NPFH100FX, NPFH100FY, NPFH100FZ, NPFH100GA, NPFH100GB, NPFH100GC, NPFH100GD, NPFH100GE, NPFH100GF, NPFH100GG, NPFH100GH, NPFH100GI, NPFH100GJ, NPFH100GK, NPFH100GL, NPFH100GM, NPFH100GN, NPFH100GO, NPFH100GP, NPFH100GQ, NPFH100GR, NPFH100GS, NPFH100GT, NPFH100GU, NPFH100GV, NPFH100GW, NPFH100GX, NPFH100GY, NPFH100GZ, NPFH100HA, NPFH100HB, NPFH100HC, NPFH100HD, NPFH100HE, NPFH100HF, NPFH100HG, NPFH100HH, NPFH100HI, NPFH100HJ, NPFH100HK, NPFH100HL, NPFH100HM, NPFH100HN, NPFH100HO, NPFH100HP, NPFH100HQ, NPFH100HR, NPFH100HS, NPFH100HT, NPFH100HU, NPFH100HV, NPFH100HW, NPFH100HX, NPFH100HY, NPFH100HZ, NPFH100IA, NPFH100IB, NPFH100IC, NPFH100ID, NPFH100IE, NPFH100IF, NPFH100IG, NPFH100IH, NPFH100II, NPFH100IJ, NPFH100IK, NPFH100IL, NPFH100IM, NPFH100IN, NPFH100IO, NPFH100IP, NPFH100IQ, NPFH100IR, NPFH100IS, NPFH100IT, NPFH100IU, NPFH100IV, NPFH100IW, NPFH100IX, NPFH100IY, NPFH100IZ, NPFH100JA, NPFH100JB, NPFH100JC, NPFH100JD, NPFH100JE, NPFH100JF, NPFH100JG, NPFH100JH, NPFH100JI, NPFH100JJ, NPFH100JK, NPFH100JL, NPFH100JM, NPFH100JN, NPFH100JO, NPFH100JP, NPFH100JQ, NPFH100JR, NPFH100JS, NPFH100JT, NPFH100JU, NPFH100JV, NPFH100JW, NPFH100JX, NPFH100JY, NPFH100JZ, NPFH100KA, NPFH100KB, NPFH100KC, NPFH100KD, NPFH100KE, NPFH100KF, NPFH100KG, NPFH100KH, NPFH100KI, NPFH100KJ, NPFH100KL, NPFH100KM, NPFH100KN, NPFH100KO, NPFH100KP, NPFH100KQ, NPFH100KR, NPFH100KS, NPFH100KT, NPFH100KU, NPFH100KV, NPFH100KW, NPFH100KX, NPFH100KY, NPFH100KZ, NPFH100LA, NPFH100LB, NPFH100LC, NPFH100LD, NPFH100LE, NPFH100LF, NPFH100LG, NPFH100LH, NPFH100LI, NPFH100LJ, NPFH100LK, NPFH100LL, NPFH100LM, NPFH100LN, NPFH100LO, NPFH100LP, NPFH100LQ, NPFH100LR, NPFH100LS, NPFH100LT, NPFH100LU, NPFH100LV, NPFH100LW, NPFH100LX, NPFH100LY, NPFH100LZ, NPFH100MA, NPFH100MB, NPFH100MC, NPFH100MD, NPFH100ME, NPFH100MF, NPFH100MG, NPFH100MH, NPFH100MI, NPFH100MJ, NPFH100MK, NPFH100ML, NPFH100MN, NPFH100MO, NPFH100MP, NPFH100MQ, NPFH100MR, NPFH100MS, NPFH100MT, NPFH100MU, NPFH100MV, NPFH100MW, NPFH100MX, NPFH100MY, NPFH100MZ, NPFH100NA, NPFH100NB, NPFH100NC, NPFH100ND, NPFH100NE, NPFH100NF, NPFH100NG, NPFH100NH, NPFH100NI, NPFH100NJ, NPFH100NK, NPFH100NL, NPFH100NM, NPFH100NN, NPFH100NO, NPFH100NP, NPFH100NQ, NPFH100NR, NPFH100NS, NPFH100NT, NPFH100NU, NPFH100NV, NPFH100NW, NPFH100NX, NPFH100NY, NPFH100NZ, NPFH100OA, NPFH100OB, NPFH100OC, NPFH100OD, NPFH100OE, NPFH100OF, NPFH100OG, NPFH100OH, NPFH100OI, NPFH100OJ, NPFH100OK, NPFH100OL, NPFH100OM, NPFH100ON, NPFH100OO, NPFH100OP, NPFH100OQ, NPFH100OR, NPFH100OS, NPFH100OT, NPFH100OU, NPFH100OV, NPFH100OW, NPFH100OX, NPFH100OY, NPFH100OZ, NPFH100PA, NPFH100PB, NPFH100PC, NPFH100PD, NPFH100PE, NPFH100PF, NPFH100PG, NPFH100PH, NPFH100PI, NPFH100PJ, NPFH100PK, NPFH100PL, NPFH100PM, NPFH100PN, NPFH100PO, NPFH100PP, NPFH100PQ, NPFH100PR, NPFH100PS, NPFH100PT, NPFH100PU, NPFH100PV, NPFH100PW, NPFH100PX, NPFH100PY, NPFH100PZ, NPFH100QA, NPFH100QB, NPFH100QC, NPFH100QD, NPFH100QE, NPFH100QF, NPFH100QG, NPFH100QH, NPFH100QI, NPFH100QJ, NPFH100QK, NPFH100QL, NPFH100QM, NPFH100QN, NPFH100QO, NPFH100QP, NPFH100QQ, NPFH100QR, NPFH100QS, NPFH100QT, NPFH100QU, NPFH100QV, NPFH100QW, NPFH100QX, NPFH100QY, NPFH100QZ, NPFH100RA, NPFH100RB, NPFH100RC, NPFH100RD, NPFH100RE, NPFH100RF, NPFH100RG, NPFH100RH, NPFH100RI, NPFH100RJ, NPFH100RK, NPFH100RL, NPFH100RM, NPFH100RN, NPFH100RO, NPFH100RP, NPFH100RQ, NPFH100RR, NPFH100RS, NPFH100RT, NPFH100RU, NPFH100RV, NPFH100RW, NPFH100RX, NPFH100RY, NPFH100RZ, NPFH100SA, NPFH100SB, NPFH100SC, NPFH100SD, NPFH100SE, NPFH100SF, NPFH100SG, NPFH100SH, NPFH100SI, NPFH100SJ, NPFH100SK, NPFH100SL, NPFH100SM, NPFH100SN, NPFH100SO, NPFH100SP, NPFH100SQ, NPFH100SR, NPFH100SS, NPFH100ST, NPFH100SU, NPFH100SV, NPFH100SW, NPFH100SX, NPFH100SY, NPFH100SZ, NPFH100TA, NPFH100TB, NPFH100TC, NPFH100TD, NPFH100TE, NPFH100TF, NPFH100TG, NPFH100TH, NPFH100TI, NPFH100TJ, NPFH100TK, NPFH100TL, NPFH100TM, NPFH100TN, NPFH100TO, NPFH100TP, NPFH100TQ, NPFH100TR, NPFH100TS, NPFH100TT, NPFH100TU, NPFH100TV, NPFH100TW, NPFH100TX, NPFH100TY, NPFH100TZ, NPFH100UA, NPFH100UB, NPFH100UC, NPFH100UD, NPFH100UE, NPFH100UF, NPFH100UG, NPFH100UH, NPFH100UI, NPFH100UJ, NPFH100UK, NPFH100UL, NPFH100UM, NPFH100UN, NPFH100UO, NPFH100UP, NPFH100UQ, NPFH100UR, NPFH100US, NPFH100UT, NPFH100UU, NPFH100UV, NPFH100UW, NPFH100UX, NPFH100UY, NPFH100UZ, NPFH100VA, NPFH100VB, NPFH100VC, NPFH100VD, NPFH100VE, NPFH100VF, NPFH100VG, NPFH100VH, NPFH100VI, NPFH100VJ, NPFH100VK, NPFH100VL, NPFH100VM, NPFH100VN, NPFH100VO, NPFH100VP, NPFH100VQ, NPFH100VR, NPFH100VS, NPFH100VT, NPFH100VU, NPFH100VV, NPFH100VW, NPFH100VX, NPFH100VY, NPFH100VZ, NPFH100WA, NPFH100WB, NPFH100WC, NPFH100WD, NPFH100WE, NPFH100WF, NPFH100WG, NPFH100WH, NPFH100WI, NPFH100WJ, NPFH100WK, NPFH100WL, NPFH100WM, NPFH100WN, NPFH100WO, NPFH100WP, NPFH100WQ, NPFH100WR, NPFH100WS, NPFH100WT, NPFH100WU, NPFH100WV, NPFH100WW, NPFH100WX, NPFH100WY, NPFH100WZ, NPFH100XA, NPFH100XB, NPFH100XC, NPFH100XD, NPFH100XE, NPFH100XF, NPFH100XG, NPFH100XH, NPFH100XI, NPFH100XJ, NPFH100XK, NPFH100XL, NPFH100XM, NPFH100XN, NPFH100XO, NPFH100XP, NPFH100XQ, NPFH100XR, NPFH100XS, NPFH100XT, NPFH100XU, NPFH100XV, NPFH100XW, NPFH100XX, NPFH100XY, NPFH100XZ, NPFH100YA, NPFH100YB, NPFH100YC, NPFH100YD, NPFH100YE, NPFH100YF, NPFH100YG, NPFH100YH, NPFH100YI, NPFH100YJ, NPFH100YK, NPFH100YL, NPFH100YM, NPFH100YN, NPFH100YO, NPFH100YP, NPFH100YQ, NPFH100YR, NPFH100YS, NPFH100YT, NPFH100YU, NPFH100YV, NPFH100YW, NPFH100YX, NPFH100YY, NPFH100YZ, NPFH100ZA, NPFH100ZB, NPFH100ZC, NPFH100ZD, NPFH100ZE, NPFH100ZF, NPFH100ZG, NPFH100ZH, NPFH100ZI, NPFH100ZJ, NPFH100ZK, NPFH100ZL, NPFH100ZM, NPFH100ZN, NPFH100ZO, NPFH100ZP, NPFH100ZQ, NPFH100ZR, NPFH100ZS, NPFH100ZT, NPFH100ZU, NPFH100ZV, NPFH100ZW, NPFH100ZX, NPFH100ZY, NPFH100ZZ	