

Anti-Hijack Alarm and Engine Immobiliser

- **Anti- Car Hijack Function**
- **Three Automatic Immobilisers**
- **Intelligent Glass Break Sensor**
- **Intelligent Dual Stage Shock Sensor**
- **Data Battery Back-Up Siren**
- **Door, bonnet and boot protection**
- **Central locking from the remote**
- **Turbo Timer Functions**
- **Alarm control via vehicle factory key**
- **Courier function**



Description

Anti-Hijack Function

When the Anti- Car Hijack Mode is activated, in a certain event the unit will auto immobilise the vehicle after a user define action.

Three automatic immobilisers

For maximum security fuel pump, ignition system and starter motor immobiliser cuts (where possible) are made so the car cannot be started unless it is disarmed via the remote. The system will immobilise 40 seconds after the ignition is turned off or when the alarm is armed.

Intelligent dual stage shock sensor

It gives a warning on a light impact and a full alarm on a heavy impact to the vehicle. It can distinguish between environmental shocks such as trucks or aircraft and a thief attempting to break in. It will auto adjust its sensitivity for the environment on arming.

Data battery back-up siren

A self powered siren that communicates independently with the alarm so it cannot be fooled into turning off like normal battery back-up sirens.

Door, bonnet and boot protection

If the alarm is armed and a door, bonnet or boot is opened the alarm will sound.

Central locking from the remote

The alarm will lock/unlock the doors when the alarm is armed/disarmed.

Turbo timer functions

The RAV3 is designed specifically to work with turbo vehicles. It has two turbo timer options to choose from.

On-board turbo timer – no need to fit an external unit - using the on-board turbo timer is the most secure way to have a turbo timer. The alarm is armed as usual but the car will continue to run for the preset run time of 1, 2 or 4 minutes. If the alarm is triggered during this time the car will shut down and the alarm will sound. It can also be turned off prior to the preset run time via the remote.

Turbo timer interface - link the alarm up with your existing external turbo timer so your car will continue to run on the external turbo timer after the alarm is armed as usual. If the alarm is triggered during this time the car will shut down and the alarm will sound.

Control the alarm with your vehicle's factory key

If your vehicle has a factory key that locks/unlocks the doors your RAV3 alarm may be able to interface with it so the alarm arms/disarms at the same time. Boot release will also work from the factory key (and if the alarm is armed it will disarm). This feature will work with most factory keys.

NEW Courier function

Courier function allows the engine to continue running indefinitely while the system is armed. If the alarm is triggered during this time the car will shut down and the alarm will sound.

Two rolling code 4 button waterproof remotes

(If you are not using your car's factory key to operate the alarm).

Product Includes

- 1 x ASA 3-Point Engine Immobiliser
- 2 x 4-Button Rolling Code Waterproof Remote Controls
- 1 x Mini Coded Backup Battery Siren
- 1 x Glass Break Sensor
- 1 x Push Up Button