MULTI-ROOM WI-FI AUDIO ADAPTER WITH IR REMOTE AND OPTICAL OUTPUT

Model: WFA28
Quick Start Guide

daytonaudio.com
tel + 937.743.8248
info@daytonaudio.com

705 Pleasant Valley Dr.
Springboro, OH 45066
USA

1. Unboxing

Contents:
- Wi-Fi Audio Adapter
- 5V USB Power Adapter
- USB to Micro USB Cable
- 3.5mm Male to RCA Cable
- 3.5mm to Male to Male Cable
- Quick Start Guide
- Hi-Fly App Guide
- Screws
- Mounting Pad
- IR Remote

OPTICAL **LINE OUT** **ETHERNET** **USB** **LINE IN** **DC IN**

Wi-Fi Audio Adapter

3.5 mm to Male to RCA Cable

3.5 mm to Male to Male Cable

USB to Micro USB Cable

5V USB Power Adapter

IR Remote

2. Connections

OPTICAL **LINE OUT** **ETHERNET** **USB** **LINE IN** **DC IN**

USB Power Adapter

Active Speakers

OR

Audio Amplifier

Router

Audio File Playback

Smartphone or any analog source

3. IR Remote

MUTE

VOL+

VOL-

1   2

3   4

5   6

ON/OFF

MUTE   Mute

▶❙❙   Play/Pause

▶❙   Next/Forward

❙◀   Previous/Back

VOL+   Volume Up

VOL-   Volume Down

Preset buttons 1-6 (Wi-Fi Mode)
Save stations or play lists as presets.
Use the remote to access saved presets.

4. Setup

Use the App Store (iOS devices) or Google Play (Android devices) to download and install the Hi-Fly app (Wi-Fi and internet access required).

Open the App and follow the on-screen guide to set up your Wi-Fi audio network.

Note: If you use the Ethernet connection, no network setup is required. Just open the app and the device is ready for use!

*For additional information, see the Hi-Fly Audio App Guide and Product Manuals online at daytonaudio.com.