

The intelligent Doorbell

- Speak to the person at your door via your landline or mobile phone
- Leave your home, office or business never miss another delivery or visitor
- A great security product speak to any visitor without opening the door

Answer and offer reassurance to a relative's visitor remotely

• Deter potential intruders - are you in or out?

Where is it used?

- · Businesses and home based businesses
- · Domestic and home users

UNLOCKED

- · Hotels, Bed and Breakfast, Guesthouses and Hostels
- · Doctors, Dentists, Vets and other Out of Hours Services
- · Nurseries, Schools, Colleges and Universities
- · Nursing homes, Hospitals and Residential care
- · Tourist Information and Taxi firms
- Warden controlled accommodation





How does it work?

- 1. Visitor presses Doorbell
- 2. Smartbel simultaneously calls the number you set
- 3. Answer the phone and speak to the visitor remotely







How do i program the Smartbel?

Programming the Smartbel to ring any number you choose is simple:

1. Note down the number of the micro SIM card you wish to use inside the Smartbel. The unit is unlocked so any micro-SIM with credit will do.

Let's call this the Smartbel number

2. Write down the mobile phone or landline phone number you want Smartbel to call when someone presses the Doorbell.

Let's call this the Callback number

To set the number your Smartbel calls, you will need to send a text message to the Smartbel number:

!@Callback number@

Shortly after sending the text, you will receive a text message confirming that everything is set and you are ready to start using the Smartbel:

SMARTBEL: on, Signal: 23/25 strong :-D

Box Contents

- Smartbel
- · Wall bracket
- Aerial
- Doorbell (inner / outer case)
- Waterproofing cover
- AC adapter
- 1.8m USB to mini USB cable
- 5m RJ12 to RJ12 flat cable

- 30cm RJ12 to RJ12 flat cable
- 10pcs internal 3M adhesive strips
- Screws (x5)
- Wall plugs (x5)
- Rubber wall Grommets (x2)
- · Instruction booklet
- · Fixing templates

www.smartbel.com.au