

# SeKi

Medium



## Programming

### Step 1

Press buttons "A" and "Channel V" at the same time.

Press both buttons for at least 5 seconds until the corresponding indicator A lights up.

The learning system is on now.

For programming source B press button "B" instead of button "A"

### Step 2

Hold the sending end of the established remote aiming at the receiving end of SeKi. (distance 2-5cm)

### Step 3

Press the button of SeKi remote control which you want to program. The indicator will flash 3 times.



### Step 4

Press the targeted button of the original remote control. When receiving the correct data, LED will light for 1 second and then flash 3 times.

### Step 5

To learn other buttons repeat steps 3 + 4 until the end of all learning.

### Step 6

When learning is completed, press button "A" to exit learning state. If the learning system B is set at the first step, please press "B" to save and exit.

**You are done and can now use your SeKi.**

**Copy button for button**

