

WWW.BENELEC.COM.AU

# BENELEC

|  | 27MHZ  | Z UHF 477MHZ CB   |  |                               |   |  |   |   |  |   |   |   |
|--|--|---|--|-------------------------------|---|--|---|---|--|---|---|---|
| PART NUMBER(S) ANTENNA NAME                  | OZ15Z<br>REDBACK                                       | OZ623<br>HI-GLASS   | 026231 (STEEL)<br>026231BK (BLACK)<br>HI-STEEL                   | 026264<br>FAZE 4              | OZ629<br>ADVENTURER   | OZ632<br>XTENDER   | DZ634X (FIXED) DZ634XC (REMOVABLE) FLEXI-DIPOLE   | OZ634ZMC<br>RUGGED<br>FLEXI-DIPOLE  | OZ635<br>EXPLORER  | DZ637<br>TRUCKIE  | 02638 (BLACK)<br>02638W (WHITE)<br>4WHEELER   | 026383C (BLACK)<br>026383CW (WHITE)<br>UHF STUMPY                       |
| LAND MOBILE UHF/27MHZ GB & GELLULAR ANTENNAS | 926M   | Φ. D.C. M   | 67cM   | 150cm                         | 130см   | В7см   | 33cM  | ээсм  | 93см   | ВБСМ  | 30cm  | SOCM  |
| APPLICATION                                  | Mobile<br>27MHz<br>GP                                  | Mobile<br>477Mhz<br>GP  |  |                               | Mobile<br>477Mhz<br>GPI   |  |   | Mobile<br>450 -<br>520MHz<br>GPI  | Mobile<br>477MHz<br>GPI  |   |   |   |
| FEATURES                                     | Pre-tuned,<br>epoxy<br>coated,<br>rugged &<br>flexible | Ideal for<br>corru-<br>gated and<br>rough<br>roads.<br>Braided<br>conduc-<br>tor. | 17/7PH<br>polished<br>S/S<br>metal tip.<br>Rugged &<br>flexible. | Tapered<br>Epoxy.             | Rugged,<br>long<br>range.<br>Can be<br>mounted<br>anywhere<br>on vehi-<br>cle. Ideal<br>for 4WDs. | Light-<br>weight<br>GPI<br>ideally<br>suited for<br>2WD<br>vehicles. | Flexible & compact. Ideal emergency antenna for temporary replacement of large colinears. | Ultra<br>rugged,<br>broad-<br>band, flexi<br>dipole.<br>Full band<br>operation. | Rugged<br>& reliable,<br>includes<br>spare<br>emergen-<br>cy whip.<br>Ideal for<br>4WDs.<br>3dB hills,<br>6.5dB flat<br>terrain. | Hi performance/<br>range.<br>Can be<br>mounted<br>anywhere<br>on the<br>vehicle.<br>Ideal for<br>trucks.<br>Mirrors &<br>gutters. | Conve-<br>nient, all<br>situations<br>covered.<br>Rugged<br>dual<br>antenna,<br>fiberglass<br>enclosed.<br>3dB hills,<br>6.5dB flat<br>terrain. | Compact<br>and<br>rugged.<br>Fiberglass<br>enclosed.<br>Remov-<br>able. |
| LENGTH (cm)                                  | 92   | 65  | 67   | 150                           | 130   | 87   | 31(X)<br>33(XC)   | 33  | 93 (6.5)<br>16 (3)   | 85  | 120 (6.5)<br>50 (3)   | 50  |
| GAIN (dB)                                    | 0  | 4.  | .5   | 6                             | 9   | 6.5  | 4   | 4   | 3 / 6.5  | 6.5   | 4 / 6.5   | 3   |
| TERMINATION                                  | VHF Base<br>5/16" F<br>thread                          | 5/16  | UHF Base<br>5" female thi  | read<br>I ( <b>Ground P</b> I | UHF<br>M-Base UHF<br>Base (   |  | Stud (X)  UHF M- Base (XC)  | UHF<br>M-Base<br><b>GP</b> (Gro   | 5m RG58, FMEs, UHFp adaptor (supplied)  ound Plane) Refer to back page   |   |   |   |


dB gain reference is relative to 1/4 wave on ground plane.

**GPI (Ground Plane Independent)**Antenna operates independently of vehicle and can be mounted anywhere.

**GP (Ground Plane)**Antenna requires UHF antenna base with contact to vehicle to operate.

Refer to back page for an in-depth antenna guide.

# BENELEC



dB gain reference is relative to 1/4 wave on ground plane.

**GPI (Ground Plane Independent)**Antenna operates independently of vehicle and can be mounted anywhere.

**GP (Ground Plane)**Antenna requires UHF antenna base with contact to vehicle to operate.

Refer to back page for an in-depth antenna guide.

## **ANTENNA ACCESSORIES**

| МОЦ                                | INTING, BASES, LEADS & MORE   |  |  |  |  |  |  |  |
|------------------------------------|---|--|--|--|--|--|--|--|
| MOBILE ANTENNA MOUNTING            |   |  |  |  |  |  |  |  |
| 02714S                             | Fold Down Gutter Bracket S/S  |  |  |  |  |  |  |  |
| 02726S                             | Heavy Duty Gutter Bracket S/S   |  |  |  |  |  |  |  |
| 02728                              | Mirror/Roof Bracket Bar S/S   |  |  |  |  |  |  |  |
| 02728B                             | Mirror/Roof Bracket Bar ZPS   |  |  |  |  |  |  |  |
| 02729                              | Wall Bracket 100mm S/S  |  |  |  |  |  |  |  |
| 027291                             | Light Weight L Bracket S/S  |  |  |  |  |  |  |  |
| 02730                              | Bull Bar Bracket - Right Angle S/S                                      |  |  |  |  |  |  |  |
| 02730B                             | Bull Bar Bracket - Right Angle ZPS                                      |  |  |  |  |  |  |  |
| 027303                             | Adjustible Swivel "Lip" Mount   |  |  |  |  |  |  |  |
| 027313                             | Wrap Around Bull Bar Bracket 45mm                                       |  |  |  |  |  |  |  |
| 027314                             | Wrap Around Bull Bar Bracket 50mm                                       |  |  |  |  |  |  |  |
| 02732                              | Heavy Duty Bull Bar Bracket 64mm Tube S/S                               |  |  |  |  |  |  |  |
| 027321                             | Heavy Duty Bull Bar Bracket 76mm Tube S/S                               |  |  |  |  |  |  |  |
| 02734                              | 'Z' Trunk Groove Bracket S/S  |  |  |  |  |  |  |  |
| 02734B                             | 'Z' Trunk Groove Bracket ZPS  |  |  |  |  |  |  |  |
| 027423                             | 'Super Sucker' Magnetic Suction Base 16mm Hole                          |  |  |  |  |  |  |  |
| 02795                              | UHF Adaptor 5/16" Male to M Base  |  |  |  |  |  |  |  |
| BASE ANTENNA MOUNTING              |   |  |  |  |  |  |  |  |
| 02811                              | Parrallel Mounting Bracket 90/60mm ZPS                                  |  |  |  |  |  |  |  |
| 028115                             | Parrallel Mounting Bracket 90/60mm S/S                                  |  |  |  |  |  |  |  |
|                                    | ANTENNA BASES   |  |  |  |  |  |  |  |
| 02720                              | Black VHF Standard Base 5/16" 26 TPI                                    |  |  |  |  |  |  |  |
| 02724                              | 'Big Mag' H/D 140mm Mag Base - M Base/UHF Socket<br>& 4m x RG58 to UHFp |  |  |  |  |  |  |  |
| 02740                              | UHF Standard Base 5/16" M 26TPI   |  |  |  |  |  |  |  |
| 02742                              | UHF Heavy Duty Base 5/16" Male to UHF Socket                            |  |  |  |  |  |  |  |
| MOBILE ANTENNA LEADS & ACCESSORIES |   |  |  |  |  |  |  |  |
| 10106F                             | VHF Base 3.6m RG58 & UHFp Fitted  |  |  |  |  |  |  |  |
| 101046                             | 5m FMEs to FMEs Extension Cable for 10109C                              |  |  |  |  |  |  |  |
| 10108                              | UHF Base 3.6m RG58 to UHFp Fitted                                       |  |  |  |  |  |  |  |
| 10109                              | UHF M Base 5m RG58 to FME Socket Fitted                                 |  |  |  |  |  |  |  |
| 10109C                             | UHF M Base 450mm LL100 Black to FME Plug                                |  |  |  |  |  |  |  |
| 10101                              | Jumper Lead UHFp to UHP 350mm   |  |  |  |  |  |  |  |
| 173810                             | UHF 2Way Switch - 2 in x 1 out  |  |  |  |  |  |  |  |
|                                    | NTENNA LEADS  |  |  |  |  |  |  |  |
| 101210                             | UHF Plug to N Plug 10m x RG213  |  |  |  |  |  |  |  |
| 101215                             | UHF Plug to N Plug 15m x RG213  |  |  |  |  |  |  |  |
|                                    | VER LEADS   |  |  |  |  |  |  |  |
| 10505                              | 2 Pin, 2 Amp In-Line Fuse & Holder Suitable for Uniden                  |  |  |  |  |  |  |  |
| 10507                              | 2 Pin "T" Secure Plug 4mm² x 20 Amp Fused + & -ve                       |  |  |  |  |  |  |  |
| 10510                              | 2 Pin, 2 Amp In-Line Fuse & Holder Suitable for GME                     |  |  |  |  |  |  |  |

ANTENNA TEST INSTRUMENT

VSWR/Power Meter 1.8-525MHz




# BENELEC


## ANTENNA SELECTION GUIDE

### WHICH ANTENNA DO I NEED?

Gain describes the shape of the radiation from an antenna. Use a higher gain antenna for better performance in open flat terrain. Use a lower gain antenna for better performance in rough mountainous terrain.



We recommend the use of a lower gain antenna for the communications in vehicle convoy situations.



When operating between mountainous and open terrain, think about choosing an antenna with interchangeable high gain and low gain whip tops, or use two antennas with an RF switch.

Note that Stainless Steel whip antennas will not last on corrugated roads. They are not suitable for this application.

#### GP/GPI RADIATING PATTERNS

Ground Plane Independent (GPI) antennas can be mounted anywhere on the vehicle.

These antennas work independently of the vehicle body, and as such they provide consistent performance all the way around the antenna.





Grounded Plane (GP) antennas rely on the metal surface of the vehicle for performance. If you mount this style of antenna on the edge of a vehicle, the radiation pattern will be biased towards the area with the largest amount of metal (an offset pattern).



There will also be a deterioration in the VSWR of grounded antennas that are mounted on the edge of the vehicle. Grounded antennas generally should only be mounted in the centre of the vehicle roof.

### CONNECTOR ADVICE

We recommend to add a thread locking adhesive (eg Loctite 242 Blue – Threadlocker Medium Strength) at the interface between the cable connector (FME socket) and the UHF plug adaptor as it's possible for this connection to vibrate loose over time.

Exposed connectors should be sealed with self amalgamating tape such as Benelec P/N 5052219BK or equivalent.

#### CABLE ADVICE

Care must be taken to not damage, cut or crush the coaxial cable when routing it to the transceiver through a vehicle.

We recommend to seal any points where the cable enters the vehicle.

#### MOUNTING TIPS & ADVICE

- For better performance locate the antenna higher on the vehicle.
- Brackets and antenna mountings are to be secured properly.
- Antennas must be mounted vertically, this is particularly important with higher gain antennas.
- Avoid affixing any object to the antenna as it could affect the performance of the communications system.
- Ground Plane antennas need to be fitted direct to vehicle panels, as bracket mounting will compromise the performance.
- Do not mount antennas close to each other. Min distance should be 70cm between antennas. The further apart the two antennas, the better the performance of each respective antenna.
- Do not mount antennas closer than 70cm to any metal vertical surface.
- Do not mount antennas operating on the same band, at the same horizontal level unless a switch selects them.

#### **Available from:**

BENELEC PTY LTD